













CUTMASTER® 60i

PLASMA CUTTING SYSTEM

OPERATING MANUAL



Revision: AB

Issue Date: April 3, 2017

Manual No.: 0-5436



WE APPRECIATE YOUR BUSINESS!

Congratulations on your new Thermal Dynamics product. We are proud to have you as our customer and will strive to provide you with the best service and reliability in the industry. This product is backed by our extensive warranty and world-wide service network. To locate your nearest distributor or service agency call 1-800-426-1888, or visit us on the web at **www.esab.com**.

This Operating Manual has been designed to instruct you on the correct use and operation of your Thermal Dynamics product. Your satisfaction with this product and its safe operation is our ultimate concern. Therefore please take the time to read the entire manual, especially the Safety Precautions. They will help you to avoid potential hazards that may exist when working with this product.

YOU ARE IN GOOD COMPANY!

The Brand of Choice for Contractors and Fabricators Worldwide.

Thermal Dynamics is a Global Brand of manual and automation Plasma Cutting Products for ESAB.

We distinguish ourselves from our competition through market-leading, dependable products that have stood the test of time. We pride ourselves on technical innovation, competitive prices, excellent delivery, superior customer service and technical support, together with excellence in sales and marketing expertise.

Above all, we are committed to developing technologically advanced products to achieve a safer working environment within the welding industry.

\triangle

WARNING

Read and understand this entire Manual and your employer's safety practices before installing, operating, or servicing the equipment.

While the information contained in this Manual represents the Manufacturer's best judgement, the Manufacturer assumes no liability for its use.

Plasma Cutting Power Supply CutMaster™ 60i SL60QD™ 1Torch™ Operating Manual Number 0-5436

Published by: ESAB Group Incorporated 2800 Airport Rd. Denton, Texas 76207

www.esab.com

© Copyright 2016 by Thermal Dynamics an ESAB brand.

All rights reserved.

Reproduction of this work, in whole or in part, without written permission of the publisher is prohibited.

The publisher does not assume and hereby disclaims any liability to any party for any loss or damage caused by any error or omission in this Manual, whether such error results from negligence, accident, or any other cause.

For Material Print Specifications, refer to document 47x1948 Original Publication Date: December 12, 2016 Revision Date: April 3, 2017

Record the following information for Warranty purposes:

Where Purchased:	
Purchase Date:	
Power Supply Serial #:	
Torch Serial #:	



Be sure this information reaches the operator. You can get extra copies through your supplier.

CAUTION

These INSTRUCTIONS are for experienced operators. If you are not fully familiar with the principles of operation and safe practices for arc welding and cutting equipment, we urge you to read our booklet, "Precautions and Safe Practices for Arc Welding, Cutting, and Gouging," Booklet 0-5407. Do NOT permit untrained persons to install, operate, or maintain this equipment. Do NOT attempt to install or operate this equipment until you have read and fully understand these instructions. If you do not fully understand these instructions, contact your supplier for further information. Be sure to read the Safety Precautions before installing or operating this equipment.

USER RESPONSIBILITY

This equipment will perform in conformity with the description thereof contained in this manual and accompanying labels and/or inserts when installed, operated, maintained and repaired in accordance with the instructions provided. This equipment must be checked periodically. Malfunctioning or poorly maintained equipment should not be used. Parts that are broken, missing, worn, distorted or contaminated should be replaced immediately. Should such repair or replacement become necessary, the manufacturer recommends that a telephone or written request for service advice be made to the Authorized Distributor from whom it was purchased.

This equipment or any of its parts should not be altered without the prior written approval of the manufacturer. The user of this equipment shall have the sole responsibility for any malfunction which results from improper use, faulty maintenance, damage, improper repair or alteration by anyone other than the manufacturer or a service facility designated by the manufacturer.



READ AND UNDERSTAND THE INSTRUCTION MANUAL BEFORE INSTALLING OR OPERATING.

PROTECT YOURSELF AND OTHERS!

ASSUREZ-VOUS QUE CETTE INFORMATION EST DISTRIBUÉE À L'OPÉRATEUR. VOUS POUVEZ OBTENIR DES CO<u>PIES SUPPLÉMENTAIRES CHEZ VOTRE FOURNISSEUR.</u>


MISE EN GARDE

Les INSTRUCTIONS suivantes sont destinées aux opérateurs qualifiés seulement. Si vous n'avez pas une connaissance approfondie des principes de fonctionnement et des règles de sécurité pour le soudage à l'arc et l'équipement de coupage, nous vous suggérons de lire notre brochure « Precautions and Safe Practices for Arc Welding, Cutting and Gouging, » Brochure 0-5407. Ne permettez PAS aux personnes non qualifiées d'installer, d'opérer ou de faire l'entretien de cet équipement. Ne tentez PAS d'installer ou d'opérer cet équipement avant de lire et de bien comprendre ces instructions. Si vous ne comprenez pas bien les instructions, communiquez avec votre fournisseur pour plus de renseignements. Assurez-vous de lire les Règles de Sécurité avant d'installer ou d'opérer cet équipement.

RESPONSABILITÉS DE L'UTILISATEUR

Cet équipement opérera conformément à la description contenue dans ce manuel, les étiquettes d'accompagnement et/ou les feuillets d'information si l'équipement est installé, opéré, entretenu et réparé selon les instructions fournies. Vous devez faire une vérification périodique de l'équipement. Ne jamais utiliser un équipement qui ne fonctionne pas bien ou n'est pas bien entretenu. Les pièces qui sont brisées, usées, déformées ou contaminées doivent être remplacées immédiatement. Dans le cas où une réparation ou un remplacement est nécessaire, il est recommandé par le fabricant de faire une demande de conseil de service écrite ou par téléphone chez le Distributeur Autorisé de votre équipement.

Cet équipement ou ses pièces ne doivent pas être modifiés sans permission préalable écrite par le fabricant. L'utilisateur de l'équipement sera le seul responsable de toute défaillance résultant d'une utilisation incorrecte, un entretien fautif, des dommages, une réparation incorrecte ou une modification par une personne autre que le fabricant ou un centre de service désigné par le fabricant.



ASSUREZ-VOUS DE LIRE ET DE COMPRENDRE LE MANUEL D'UTILISATION AVANT D'INSTALLER OU D'OPÉRER L'UNITÉ.

PROTÉGEZ-VOUS ET LES AUTRES!



TABLE OF CONTENTS

SECTION 1:		
GENERAL	INFORMATION	1-1
1.01	Notes, Cautions and Warnings	1-1
1.02	Important Safety Precautions	1-1
1.03	Publications	1-2
1.04	Note, Attention et Avertissement	1-3
1.05	Précautions De Sécurité Importantes	1-3
1.06	Documents De Reference	1-6
1.07	Statement of Warranty	1-7
SECTION 2 SYS		0.4
INTRODUC 2.01		
2.01	How To Use This Manual Equipment Identification	
2.02	Receipt Of Equipment	
2.03	Power Supply Specifications	
2.04	Input Wiring Specifications	
2.06	Power Supply Features	
		Δ-ι
SECTION 2 TOR INTRODUC		2 T -1
2T.01	Scope of Manual	
2T.02	General Description	2T-1
2T.03	Specifications	2T-1
2T.04	Quick Connection Torch	2T-2
2T.05	Options And Accessories	2T-2
2T.06	Introduction to Plasma	2T-2
SECTION 3 SYS		
	FION	
3.01	Unpacking	
3.02	Lifting Options	
3.03	Opening the Main Switch Cover	
3.04	Primary Input Power Connections, SINGLE Phase	
3.05	Primary Input Power Connections, THREE Phase	
3.06	Gas Connections	
3.07	Work Lead Connections	3-1
SECTION 3 TOR INSTALLAT		3T-1
3T.01	Torch Connections	
3T.02	Setting Up Mechanical Torch	
SECTION 4 SYS		
)N	
4.01	Front Panel Controls / Features	
4.02	Preparations for Operation	4-4

TABLE OF CONTENTS

SECTION 4	4 TORCI	Н:	
_	RATION		
	4T.01	Torch Parts Selection	
	4T.02	Cut Quality	
	4T.03	General Cutting Information	
	4T.04	Hand Torch Operation	
	4T.05	Gouging	
	4T.06	Mechanized Torch Operation	
	4T.07	Parts Selection for Manual and Mechanized Torch Cutting	
	4T.08	Recommended Cutting Speeds With Exposed Tip	
	4T.09	Recommended Cutting Speeds With Shielded Tip	41-12
PATENT IN	NFORM <i>i</i>	ATION	4T-15
SECTION	5 SYSTE	EM:	
	5.01	General Maintenance	
	5.02	Maintenance Schedule	
	5.03	Common Faults	
	5.04	Fault Indicator	
	5.05	Basic Troubleshooting Guide	
	5.06	Power Supply Basic Parts Replacement	5-8
SECTION			
	5T.01	General Maintenance	
	5T.02	Inspection and Replacement of Consumable Torch Parts	51-2
SECTION			
		S	
	6.01	Introduction	
	6.02 6.03	Ordering Information	
	6.04	Power Supply Replacement	
	6.05	Options and Accessories	
	6.06	External Replacement Parts (Plastic)	
	6.07	Replacement Parts for Hand Torch	
	6.08	Torch Consumable Parts (SL60)	
	6.09	Torch Consumable Parts (SL100)	
APPENDIX	(1: DAT	TA TAG INFORMATION	
		RCH PIN - OUT DIAGRAMS	
		RCH CONNECTION DIAGRAMS	
		STEM SCHEMATIC, 1PHASE 208/460V UNITS	
		STEM SCHEMATIC, 3PHASE 208/460V UNITS	
VDDENIJI	/ ፍ· Dili	RI ICATION LISTORY	ΛО

SECTION 1: GENERAL INFORMATION

1.01 Notes, Cautions and Warnings

Throughout this manual, notes, cautions, and warnings are used to highlight important information. These highlights are categorized as follows:

NOTE

An operation, procedure, or background information which requires additional emphasis or is helpful in efficient operation of the system.



CAUTION

A procedure which, if not properly followed, may cause damage to the equipment.



WARNING

A procedure which, if not properly followed, may cause injury to the operator or others in the operating area.



WARNING

Gives information regarding possible electrical shock injury. Warnings will be enclosed in a box such as this.

1.02 Important Safety Precautions



WARNING

OPERATION AND MAINTENANCE OF PLASMA ARC EQUIPMENT CAN BE DANGEROUS AND HAZARDOUS TO YOUR HEALTH.

Plasma arc cutting produces intense electric and magnetic emissions that may interfere with the proper function of cardiac pacemakers, hearing aids, or other electronic health equipment. Persons who work near plasma arc cutting applications should consult their medical health professional and the manufacturer of the health equipment to determine whether a hazard exists.

To prevent possible injury, read, understand and follow all warnings, safety precautions and instructions before using the equipment. Call 1-603-298-5711 or your local distributor if you have any questions.



GASES AND FUMES

Gases and fumes produced during the plasma cutting process can be dangerous and hazardous to your health.

- Keep all fumes and gases from the breathing area. Keep your head out of the welding fume plume.
- Use an air-supplied respirator if ventilation is not adequate to remove all fumes and gases.
- The kinds of fumes and gases from the plasma arc depend on the kind of metal being used, coatings on the metal, and the different processes. You must be very careful when cutting or welding any metals which may contain one or more of the following:

Antimony	Chromium	Mercury
Arsenic	Cobalt	Nickel
Barium	Copper	Selenium
Beryllium	Lead	Silver
Cadmium	Manganese	Vanadium

- Always read the Material Safety Data Sheets (SDS/GHS) that should be supplied with the material you are using. These SDS/GHSs will give you the information regarding the kind and amount of fumes and gases that may be dangerous to your health.
- For information on how to test for fumes and gases in your workplace, refer to item 1 in "1.03 Publications" on page 1-2 in this manual.
- Use special equipment, such as water or down draft cutting tables, to capture fumes and gases.
- Do not use the plasma torch in an area where combustible or explosive gases or materials are located.
- Phosgene, a toxic gas, is generated from the vapors of chlorinated solvents and cleansers. Remove all sources of these vapors.
- WARNING: This product contains chemicals, including lead, known to the State of California to cause birth defects and other reproductive harm.
 Wash hands after handling.



ELECTRIC SHOCK

Electric Shock can injure or kill. The plasma arc process uses and produces high voltage electrical energy. This electric energy can cause severe or fatal shock to the operator or others in the workplace.

CUTMASTER 60i

- Never touch any parts that are electrically "live" or "hot."
- Wear dry gloves and clothing. Insulate yourself from the work piece or other parts of the welding circuit.
- Repair or replace all worn or damaged parts.
- Extra care must be taken when the workplace is moist or damp.
- Install and maintain equipment according to NEC code, refer to item 9 in Section "1.03 Publications" on page 1-2.
- Disconnect power source before performing any service or repairs.
- Read and follow all the instructions in the Operating Manual.



FIRE AND EXPLOSION

Fire and explosion can be caused by hot slag, sparks, or the plasma arc.

- Be sure there is no combustible or flammable material in the workplace. Any material that cannot be removed must be protected.
- Ventilate all flammable or explosive vapors from the workplace.
- Do not cut or weld on containers that may have held combustibles.
- Provide a fire watch when working in an area where fire hazards may exist.
- Hydrogen gas may be formed and trapped under aluminum workpieces when they are cut underwater or while using a water table. DO NOT cut aluminum alloys underwater or on a water table unless the hydrogen gas can be eliminated or dissipated. Trapped hydrogen gas that is ignited will cause an explosion.



NOISE

Noise can cause permanent hearing loss. Plasma arc processes can cause noise levels to exceed safe limits. You must protect your ears from loud noise to prevent permanent loss of hearing.

- To protect your hearing from loud noise, wear protective ear plugs and/or ear muffs. Protect others in the workplace.
- Noise levels should be measured to be sure the decibels (sound) do not exceed safe levels.
- For information on how to test for noise, see item 1 in Section "1.03 Publications", in this manual.



PLASMA ARC RAYS

Plasma Arc Rays can injure your eyes and burn your skin. The plasma arc process produces very bright ultra violet and infra red light. These arc rays will damage your eyes and burn your skin if you are not properly protected.

- To protect your eyes, always wear a welding helmet or shield. Also always wear safety glasses with side shields, goggles or other protective eye wear.
- Wear welding gloves and suitable clothing to protect your skin from the arc rays and sparks.
- Keep helmet and safety glasses in good condition.
 Replace lenses when cracked, chipped or dirty.
- Protect others in the work area from the arc rays. Use protective booths, screens or shields.
- Use the shade of lens as suggested in the following per ANSI/ASC Z49.1:

Arc Current	Minimum Protective Shade No.	00
Less Than 300*		9
300 - 400*	9	12
400 - 800*	10	14

* These values apply where the actual arc is clearly seen. Experience has shown that lighter filters may be used when the arc is hidden by the workpiece.



WARNING: This product contains chemicals, including lead, known to the State of California to cause birth defects and other reproductive harm. *Wash hands after handling.*

1.03 Publications

Refer to the following standards or their latest revisions for more information:

- 1. OSHA, SAFETY AND HEALTH STANDARDS, 29CFR 1910, obtainable from the Superintendent of Documents, U.S. Government Printing Office, Washington, D.C. 20402
- 2. ANSI Standard Z49.1, SAFETY IN WELDING AND CUTTING, obtainable from the American Welding Society, 550 N.W. LeJeune Rd, Miami, FL 33126
- 3. NIOSH, SAFETY AND HEALTH IN ARC WELDING AND GAS WELDING AND CUTTING, obtainable from the Superintendent of Documents, U.S. Government Printing Office, Washington, D.C. 20402
- 4. ANSI Standard Z87.1, SAFE PRACTICES FOR OC-CUPATION AND EDUCATIONAL EYE AND FACE

1-2 GENERAL INFORMATION Manual 0-5436

PROTECTION, obtainable from American National Standards Institute, 1430 Broadway, New York, NY 10018

- ANSI Standard Z41.1, STANDARD FOR MEN'S SAFETY-TOE FOOTWEAR, obtainable from the American National Standards Institute, 1430 Broadway, New York, NY 10018
- ANSI Standard Z49.2, FIRE PREVENTION IN THE USE OF CUTTING AND WELDING PROCESSES, obtainable from American National Standards Institute, 1430 Broadway, New York, NY 10018
- 7. AWS Standard A6.0, WELDING AND CUTTING CONTAINERS WHICH HAVE HELD COMBUS-TIBLES, obtainable from American Welding Society, 550 N.W. LeJeune Rd, Miami, FL 33126
- 8. NFPA Standard 51, OXYGEN-FUEL GAS SYSTEMS FOR WELDING, CUTTING AND ALLIED PROCESSES, obtainable from the National Fire Protection Association, Batterymarch Park, Quincy, MA 02269
- NFPA Standard 70, NATIONAL ELECTRICAL CODE, obtainable from the National Fire Protection Association, Batterymarch Park, Quincy, MA 02269
- 10. NFPA Standard 51B, CUTTING AND WELDING PROCESSES, obtainable from the National Fire Protection Association, Batterymarch Park, Quincy, MA 02269
- 11. CGA Pamphlet P-1, SAFE HANDLING OF COM-PRESSED GASES IN CYLINDERS, obtainable from the Compressed Gas Association, 1235 Jefferson Davis Highway, Suite 501, Arlington, VA 22202
- 12. CSA Standard W117.2, CODE FOR SAFETY IN WELDING AND CUTTING, obtainable from the Canadian Standards Association, Standards Sales, 178 Rexdale Boulevard, Rexdale, Ontario, Canada M9W 1R3
- NWSA booklet, WELDING SAFETY BIBLIOGRAPHY obtainable from the National Welding Supply Association, 1900 Arch Street, Philadelphia, PA 19103
- 14. American Welding Society Standard AWSF4.1, RECOMMENDED SAFE PRACTICES FOR THE PREPARATION FOR WELDING AND CUTTING OF CONTAINERS AND PIPING THAT HAVE HELD HAZARDOUS SUBSTANCES, obtainable from the American Welding Society, 550 N.W. LeJeune Rd, Miami, FL 33126
- 15. ANSI Standard Z88.2, PRACTICE FOR RESPIRA-TORY PROTECTION, obtainable from American National Standards Institute, 1430 Broadway, New York, NY 10018

1.04 Note, Attention et Avertissement

Dans ce manuel, les mots "note," "attention," et "avertissement" sont utilisés pour mettre en relief des informations à caractère important. Ces mises en relief sont classifiées comme suit :

NOTE

Toute opération, procédure ou renseignement général sur lequel il importe d'insister davantage ou qui contribue à l'efficacité de fonctionnement du système.



ATTENTION

Toute procédure pouvant résulter l'endommagement du matériel en cas de non-respect de la procédure en question.



AVERTISSEMENT

Toute procédure pouvant provoquer des blessures de l'opérateur ou des autres personnes se trouvant dans la zone de travail en cas de non-respect de la procédure en question.



AVERTISSEMENT

Fournit l'information concernant des dommages possibles de choc électrique. Des avertissements seront enfermés dans une boîte de ce type.

1.05 Précautions De Sécurité Importantes



AVERTISSEMENTS

L'OPÉRATION ET LA MAINTENANCE DU MATÉRIEL DE SOUDAGE À L'ARC AU JET DE PLASMA PEUVENT PRÉSENTER DES RISQUES ET DES DANGERS DE SANTÉ.

Coupant à l'arc au jet de plasma produit de l'énergie électrique haute tension et des émissions magnétique qui peuvent interférer la fonction propre d'un "pacemaker" cardiaque, les appareils auditif, ou autre matériel de santé electronique. Ceux qui travail près d'une application à l'arc au jet de plasma devrait consulter leur membre professionel de médication et le manufacturier de matériel de santé pour déterminer s'il existe des risques de santé.

Il faut communiquer aux opérateurs et au personnel TOUS les dangers possibles. Afin d'éviter les blessures possibles, lisez, comprenez et suivez tous les avertissements, toutes les précautions de sécurité et toutes les consignes avant d'utiliser le matériel. Composez le + 603-298-5711 ou votre distributeur local si vous avez des questions.



FUMÉE et GAZ

La fumée et les gaz produits par le procédé de jet de plasma peuvent présenter des risques et des dangers de santé.

- Eloignez toute fumée et gaz de votre zone de respiration. Gardez votre tête hors de la plume de fumée provenant du chalumeau.
- Utilisez un appareil respiratoire à alimentation en air si l'aération fournie ne permet pas d'éliminer la fumée et les gaz.
- Les sortes de gaz et de fumée provenant de l'arc de plasma dépendent du genre de métal utilisé, des revêtements se trouvant sur le métal et des différents procédés. Vous devez prendre soin lorsque vous coupez ou soudez tout métal pouvant contenir un ou plusieurs des éléments suivants:

antimoine	cadmium	mercure
argent	chrome	nickel
arsenic	cobalt	plomb
baryum	cuivre	sélénium
béryllium	manganèse	vanadium

- Lisez toujours les fiches de données sur la sécurité des matières (sigle américain "SDS/GHS"); celles-ci devraient être fournies avec le matériel que vous utilisez. Les SDS/GHS contiennent des renseignements quant à la quantité et la nature de la fumée et des gaz pouvant poser des dangers de santé.
- Pour des informations sur la manière de tester la fumée et les gaz de votre lieu de travail, consultez l'article 1 et les documents cités à la page 5.

- Utilisez un équipement spécial tel que des tables de coupe à débit d'eau ou à courant descendant pour capter la fumée et les gaz.
- N'utilisez pas le chalumeau au jet de plasma dans une zone où se trouvent des matières ou des gaz combustibles ou explosifs.
- Le phosgène, un gaz toxique, est généré par la fumée provenant des solvants et des produits de nettoyage chlorés. Eliminez toute source de telle fumée.
- AVERTISSEMENT: Ce produit contient des produits chimiques, notamment du plomb, reconnu par l'État de la Californie pour causer des malformations congénitales et d'autres dommages touchant le système reproductif. Se laver les mains après manipulation.



CHOC ELECTRIQUE

Les chocs électriques peuvent blesser ou même tuer. Le procédé au jet de plasma requiert et produit de l'énergie électrique haute tension. Cette énergie électrique peut produire des chocs graves, voire mortels, pour l'opérateur et les autres personnes sur le lieu de travail.

- Ne touchez jamais une pièce "sous tension" ou "vive"; portez des gants et des vêtements secs. Isolez-vous de la pièce de travail ou des autres parties du circuit de soudage.
- Réparez ou remplacez toute pièce usée ou endommagée.
- Prenez des soins particuliers lorsque la zone de travail est humide ou moite.
- Montez et maintenez le matériel conformément au Code électrique national des Etats-Unis. (Voir la page 5, article 9.)
- Débranchez l'alimentation électrique avant tout travail d'entretien ou de réparation.
- Lisez et respectez toutes les consignes du Manuel de consignes.



INCENDIE ET EXPLOSION

Les incendies et les explosions peuvent résulter des scories chaudes, des étincelles ou de l'arc de plasma. Le procédé à l'arc de plasma produit du métal, des étincelles, des scories chaudes pouvant mettre le feu aux matières combustibles ou provoquer l'explosion de fumées inflammables.

- Soyez certain qu'aucune matière combustible ou inflammable ne se trouve sur le lieu de travail. Protégez toute telle matière qu'il est impossible de retirer de la zone de travail.
- Procurez une bonne aération de toutes les fumées inflammables ou explosives.
- Ne coupez pas et ne soudez pas les conteneurs ayant pu renfermer des matières combustibles.
- Prévoyez une veille d'incendie lors de tout travail dans une zone présentant des dangers d'incendie.
- Le gas hydrogène peut se former ou s'accumuler sous les pièces de travail en aluminium lorsqu'elles sont coupées sous l'eau ou sur une table d'eau. NE PAS couper les alliages en aluminium sous l'eau ou sur une table d'eau à moins que le gas hydrogène peut s'échapper ou se dissiper. Le gas hydrogène accumulé explosera si enflammé.



RAYONS D'ARC DE PLASMA

Les rayons provenant de l'arc de plasma peuvent blesser vos yeux et brûler votre peau. Le procédé à l'arc de plasma produit une lumière infra-rouge et des rayons ultra-violets très forts. Ces rayons d'arc nuiront à vos yeux et brûleront votre peau si vous ne vous protégez pas correctement.

- Pour protéger vos yeux, portez toujours un casque ou un écran de soudeur. Portez toujours des lunettes de sécurité munies de parois latérales ou des lunettes de protection ou une autre sorte de protection oculaire.
- Portez des gants de soudeur et un vêtement protecteur approprié pour protéger votre peau contre les étincelles et les rayons de l'arc.
- Maintenez votre casque et vos lunettes de protection en bon état. Remplacez toute lentille sale ou comportant fissure ou rognure.
- Protégez les autres personnes se trouvant sur la zone de travail contre les rayons de l'arc en fournissant des cabines ou des écrans de protection.
- Utilisez la nuance de lentille qui est suggèrée dans le recommendation qui suivent ANSI/ASC Z49.1:

Nuance MinimumNuance Suggerée Courant Arc Protective Numéro Numéro					
Courant Arc	Protective Numero	Numero			
Moins de 300*	8	9			
300 - 400*	9	12			
400 - 800*	10	14			

* Ces valeurs s'appliquent ou l'arc actuel est observé clairement. L'experience a démontrer que les filtres moins foncés peuvent être utilisés quand l'arc est caché par moiceau de travail.



BRUIT

Le bruit peut provoquer une perte permanente de l'ouïe. Les procédés de soudage à l'arc de plasma peuvent provoquer des niveaux sonores supérieurs aux limites normalement acceptables. Vous dú4ez vous protéger les oreilles contre les bruits forts afin d'éviter une perte permanente de l'ouïe.

- Pour protéger votre ouïe contre les bruits forts, portez des tampons protecteurs et/ou des protections auriculaires. Protégez également les autres personnes se trouvant sur le lieu de travail.
- Il faut mesurer les niveaux sonores afin d'assurer que les décibels (le bruit) ne dépassent pas les niveaux sûrs.
- Pour des renseignements sur la manière de tester le bruit, consultez l'article 1, page 5.



AVERTISSEMENT: Ce produit contient des produits chimiques, notamment du plomb, reconnu par l'État de la Californie pour causer des malformations congénitales et d'autres dommages touchant le système reproductif. *Se laver les mains après manipulation.*

1.06 Documents De Reference

Consultez les normes suivantes ou les révisions les plus récentes ayant été faites à celles-ci pour de plus amples renseignements :

- 1. OSHA, NORMES DE SÉCURITÉ DU TRAVAIL ET DE PROTECTION DE LA SANTÉ, 29CFR 1910, disponible auprès du Superintendent of Documents, U.S. Government Printing Office, Washington, D.C. 20402
- 2. Norme ANSI Z49.1, LA SÉCURITÉ DES OPÉRATIONS DE COUPE ET DE SOUDAGE, disponible auprès de la Société Américaine de Soudage (American Welding Society), 550 N.W. LeJeune Rd., Miami, FL 33126
- 3. NIOSH, LA SÉCURITÉ ET LA SANTÉ LORS DES OPÉRATIONS DE COUPE ET DE SOUDAGE À L'ARC ET AU GAZ, disponible auprès du Superintendent of Documents, U.S. Government Printing Office, Washington, D.C. 20402
- 4. Norme ANSI Z87.1, PRATIQUES SURES POUR LA PROTECTION DES YEUX ET DU VISAGE AU TRAVAIL ET DANS LES ECOLES, disponible de l'Institut Américain des Normes Nationales (American National Standards Institute), 1430 Broadway, New York, NY 10018
- 5. Norme ANSI Z41.1, NORMES POUR LES CHAUSSURES PROTECTRICES, disponible auprès de l'American National Standards Institute, 1430 Broadway, New York, NY 10018
- 6. Norme ANSI Z49.2, PRÉVENTION DES INCENDIES LORS DE L'EMPLOI DE PROCÉDÉS DE COUPE ET DE SOUDAGE, disponible auprès de l'American National Standards Institute, 1430 Broadway, New York, NY 10018
- 7. Norme A6.0 de l'Association Américaine du Soudage (AWS), LE SOUDAGE ET LA COUPE DE CONTENEURS AYANT RENFERMÉ DES PRODUITS COMBUSTIBLES, disponible auprès de la American Welding Society, 550 N.W. LeJeune Rd., Miami, FL 33126
- 8. Norme 51 de l'Association Américaine pour la Protection contre les Incendies (NFPA), LES SYSTEMES À GAZ AVEC ALIMENTATION EN OXYGENE POUR LE SOUDAGE, LA COUPE ET LES PROCÉDÉS ASSOCIÉS, disponible auprès de la National Fire Protection Association, Batterymarch Park, Quincy, MA 02269
- 9. Norme 70 de la NFPA, CODE ELECTRIQUE NATIONAL, disponible auprès de la National Fire Protection Association, Batterymarch Park, Quincy, MA 02269
- 10. Norme 51B de la NFPA, LES PROCÉDÉS DE COUPE ET DE SOUDAGE, disponible auprès de la National Fire Protection Association, Batterymarch Park, Quincy, MA 02269
- 11. Brochure GCA P-1, LA MANIPULATION SANS RISQUE DES GAZ COMPRIMÉS EN CYLINDRES, disponible auprès de l'Association des Gaz Comprimés (Compressed Gas Association), 1235 Jefferson Davis Highway, Suite 501, Arlington, VA 22202
- 12. Norme CSA W117.2, CODE DE SÉCURITÉ POUR LE SOUDAGE ET LA COUPE, disponible auprès de l'Association des Normes Canadiennes, Standards Sales, 178 Rexdale Boulevard, Rexdale, Ontario, Canada, M9W 1R3
- 13. Livret NWSA, BIBLIOGRAPHIE SUR LA SÉCURITÉ DU SOUDAGE, disponible auprès de l'Association Nationale de Fournitures de Soudage (National Welding Supply Association), 1900 Arch Street, Philadelphia, PA 19103
- 14. Norme AWSF4.1 de l'Association Américaine de Soudage, RECOMMANDATIONS DE PRATIQUES SURES POUR LA PRÉPARATION À LA COUPE ET AU SOUDAGE DE CONTENEURS ET TUYAUX AYANT RENFERMÉ DES PRODUITS DANGEREUX , disponible auprès de la American Welding Society, 550 N.W. LeJeune Rd., Miami, FL 33126
- 15. Norme ANSI Z88.2, PRATIQUES DE PROTECTION RESPIRATOIRE, disponible auprès de l'American National Standards Institute, 1430 Broadway, New York, NY 10018

1-6 GENERAL INFORMATION Manual 0-5436

1.07 Statement of Warranty

LIMITED WARRANTY: Subject to the terms and conditions established below, ESAB warrants to the original retail purchaser that new Thermal Dynamics CUTMASTER™ plasma cutting systems sold after the effective date of this warranty are free of defects in material and workmanship. Should any failure to conform to this warranty appear within the applicable period stated below, ESAB shall, upon notification thereof and substantiation that the product has been stored operated and maintained in accordance with Thermal Dynamics' specifications, instructions, recommendations and recognized industry practice, correct such defects by suitable repair or replacement.

This warranty is exclusive and in lieu of any warranty of merchantability or fitness for a particular purpose.

ESAB will repair or replace, at its discretion, any warranted parts or components that fail due to defects in material or workmanship within the time periods set out below. ESAB must be notified within 30 days of any failure, at which time ESAB will provide instructions on the warranty procedures to be implemented.

ESAB will honor warranty claims submitted within the warranty periods listed below. All warranty periods begin on the date of sale of the product to the original retail customer or 1 year after sale to an authorized Thermal Dynamics Distributor.

LIMITED WARRANTY PERIOD

Product	Power Supply Components (Parts and Labor)		Torch and Leads (Parts and Labor)
	U.S.	Non U.S.	
CUTMASTER™ 60i	4 Years	3 Years	1 Year

This warranty does not apply to:

- 1. Consumable Parts, such as tips, electrodes, shield cups, o-rings, starter cartridges, gas distributors, fuses, filters.
- 2. Equipment that has been modified by an unauthorized party, improperly installed, improperly operated or misused based upon industry standards.

In the event of a claim under this warranty, the remedies shall be, at the discretion of ESAB:

- 1. Repair of the defective product.
- 2. Replacement of the defective product.
- 3. Reimbursement of reasonable costs of repair when authorized in advance by Thermal Dynamics.
- 4. Payment of credit up to the purchase price less reasonable depreciation based on actual use.

These remedies may be authorized by Thermal Dynamics and are FOB West Lebanon, NH or an authorized ESAB service station. Product returned for service is at the owner's expense and no reimbursement of travel or transportation is authorized.

LIMITATION OF LIABILITY: ESAB shall not under any circumstances be liable for special or consequential damages such as, but not limited to, damage or loss of purchased or replacement goods or claims of customer of distributors (hereinafter "Purchaser") for service interruption. The remedies of the Purchaser set forth herein are exclusive and the liability of ESAB with respect to any contract, or anything done in connection therewith such as the performance or breach thereof, or from the manufacture, sale, delivery, resale, or use of the goods covered by or furnished by ESAB whether arising out of contract, negligence, strict tort, or under any warranty, or otherwise, shall not, except as expressly provided herein, exceed the price of the goods upon which liability is based.

This warranty becomes invalid if replacement parts or accessories are used which may impair the safety or performance of any Thermal Dynamics product.

This warranty is invalid if the Thermal Dynamics product is sold by non - authorized persons.

Effective December 12, 2016





This Page Intentionally Blank

SECTION 2 SYSTEM: INTRODUCTION

2.01 How To Use This Manual

This Owner's Manual applies to just product(s) listed on page i.

To ensure safe operation, read the entire manual, including the chapter on safety instructions and warnings.

Throughout this manual, the words WARNING, CAUTION, and NOTE may appear. Pay particular attention to the information provided under these headings. These special annotations are easily recognized as follows:



NOTE!

An operation, procedure, or background information which requires additional emphasis or is helpful in efficient operation of the system.



CAUTION

A procedure which, if not properly followed, may cause damage to the equipment.



WARNING

A procedure which, if not properly followed, may cause injury to the operator or others in the operating area.



WARNING

Gives information regarding possible electrical shock injury. Warnings will be enclosed in a box such as this.

Additional copies of this manual may be purchased by contacting Thermal Dynamics at the address and phone number in your area listed on back cover of this manual. Include the Operating Manual number and equipment identification numbers.

Electronic copies of this manual can also be downloaded at no charge in Acrobat PDF format by going to the ESAB web site listed below and clicking on "Product Support" / "ESAB Documentation": / "Download Library", then navigate to "Plasma Equipment" and then "Manual".

http://www.esab.com

2.02 Equipment Identification

The unit's identification number (specification or part number), model, and serial number usually appear on a data tag attached to the bottom. Equipment which does not have a data tag such as torch and cable assemblies are identified only by the specification or part number printed on loosely attached card or the shipping container. Record these numbers on the bottom of page i for future reference.

2.03 Receipt Of Equipment

When you receive the equipment, check it against the invoice to make sure it is complete and inspect the equipment for possible damage due to shipping. If there is any damage, notify the carrier immediately to file a claim. Furnish complete information concerning damage claims or shipping errors to the location in your area listed on the back cover of this manual.

Include all equipment identification numbers as described above, along with a full description of the parts in error.



Included items:

- 60i Power Supply
- SL60QDTM Torch and Leads
- Work Lead with Work Clamp
- Spare Parts Kit (2 Electrodes, 2 Tips, 1 Shield cup)
- Operating Manual
- Filter Wrench

Move the equipment to the installation site before un-boxing the unit. Use care to avoid damaging the equipment when opening the box.

2.04 Power Supply Specifications

1 Phase

60i 1 Phase Power Supply Specifications					
Input Power	208 - 480 VA	C(187 - 528 V	AC), Single Ph	nase, 50/60 Hz	
1 Phase Input Power Cable		Power Supply includes 9' single phase 8AWG 3/C input cable with NEMA 6-50P Plug			
Output Current	10 - (60 Amps, Con	tinuously Adju	stable	
Power Supply Gas Filtering Ability		Particulates	to 5 Microns		
Maximum Inlet Pressure		125 PSI	(8.6 bar)		
60i	60i Power Supply Duty Cycle *				
Ambient Air Temperature Duty Cycle Ratings @ 40° C (104° F) Operating Range 0° - 50° C					
			Rating		
	Duty Cycle	50%	60%	100%	
All Units	Current	60 Amps	50 Amps	40 Amps	
	DC Voltage	126	122	119	
* NOTE: The duty cycle will be reduced if the primary input power (AC) is low or the output voltage (DC) is higher than shown in this chart.					

3 Phase

60i 3 Phase Power Supply Specifications				
208 - 480 VAC(187 - 528 VAC), 3 Phase, 50/60 Hz				
Power Supply includes 9' single phase 12AWG 4/C input cable without plug				
10 - (60 Amps, Con	tinuously Adju	stable	
	Particulates to 5 Microns			
125 PSI (8.6 bar)				
Power Supp	oly Duty C	ycle *		
Duty Cycle Ratings @ 40° C (104° F) Operating Range 0° - 50° C				
		Rating		
Duty Cycle 50% 60% 100%			100%	
Current	60 Amps	50 Amps	40 Amps	
DC Voltage	126	122	119	
	Power Supply 10 - 0 Power Supply Duty Duty Current	208 - 480 VAC(187 - 528 Power Supply includes 9' si cable with 10 - 60 Amps, Comparticulates 125 PSI Power Supply Duty Cy Duty Cycle Ratings Operating Rational Cycle Sow Current 60 Amps	208 - 480 VAC(187 - 528 VAC), 3 Phas Power Supply includes 9' single phase 12 cable without plug 10 - 60 Amps, Continuously Adju Particulates to 5 Microns 125 PSI (8.6 bar) Power Supply Duty Cycle * Duty Cycle Ratings @ 40° C (10 Operating Range 0° - 50° C Rating Duty Cycle 50% 60% Current 60 Amps 50 Amps	

^{*} NOTE: The duty cycle will be reduced if the primary input power (AC) is low or the output voltage (DC) is higher than shown in this chart.

60i Cut Capacity				
Recommended Pierce Maximum				
5/8"	5/8"	1 1/4"		

Generator Recommendations


When using generators to power the 60i Plasma Cutting System, the following ratings are a minimum and are to be used along with the ratings listed above.

A60i Generator Specifications				
Generator Output Rating 60i Output Current Arc Characteristic				
15 kW	60A	Full		
12 kW	60A	Limited		
	45A	Full		
10 kW	45A	Limited		
I I O KVV	30A	Full		



NOTE!

Due to circuitry, age and condition two generators with the same ratings may produce different results. Adjust the amperage accordingly.



Power Supply Dimensions & Weight

Ventilation Clearance Requirements

2.05 Input Wiring Specifications



WARNING

Each CutMaster 60i system is a dedicated 1 Phase OR 3 Phase system and cannot be reconfigured to the other. Personal injury could occur if changing the phase is attempted..

1 Phase

1 Phase CutMaster 60i Power Supply Input Cable Wiring Requirements							
	Input voltage	Freq	Power Input			Suggested Sizes	
	Volts	Hz	kVA	I max	I₁eff	Fuse (amps)	Flexible Cord (Min. AWG)
	208	50/60	8.9	43	30.5	50	8 AWG (10mm²)
	230	50/60	8.9	38.9	27.6	50	10 AWG (10mm²)
1 Phase	380	50/60	8.9	23.5	16.7	30	12 AWG (2.5mm²)
I Pliase	400	50/60	8.9	22.4	15.9	30	14 AWG (2.5mm²)
	415	50/60	8.9	21.6	15.3	30	14 AWG (2.5mm²)
	480	50/60	8.9	18.6	13.2	30	14 AWG (2.5mm²)

Line Voltages with Suggested Circuit Protection and Wire Sizes Based on National Electric Code and Canadian Electric Code

Single Phase

3 Phase

3 Phase CutMaster 60i Power Supply Input Cable Wiring Requirements							
	Input voltage	Freq	Power Input			Suggested Sizes	
	Volts	Hz	kVA	I max	I ₁ eff	Fuse (amps)	Flexible Cord (Min. AWG)
	208	50/60	9.1	26	18.5	40	12 AWG (2.5mm²)
	230	50/60	9.1	23.3	16.5	30	12 AWG (2.5mm²)
3 Phase	380	50/60	8.9	13.8	9.8	20	14 AWG (2.5mm²)
3 Pilase	400	50/60	8.9	13.2	9.4	20	14 AWG (2.5mm ²)
	415	50/60	9.1	12.8	9.1	20	16 AWG (1.5mm ²)
	480	50/60	9.2	11.3	8.0	15	16 AWG (1.5mm ²)

Line Voltages with Suggested Circuit Protection and Wire Sizes
Based on National Electric Code and Canadian Electric Code

Three Phase





NOTE!

Refer to Local and National Codes or local authority having jurisdiction for proper wiring requirements.

Cable size is de-rated based on the Duty Cycle of the equipment.

2.06 Power Supply Features







This Page Intentionally Blank

SECTION 2 TORCH: INTRODUCTION

2T.01 Scope of Manual

This manual contains descriptions, operating instructions and maintenance procedures for the 1Torch Models SL60, SL60QD $^{\text{TM}}$ and SL100/Mechanized Plasma Cutting Torches. Service of this equipment is restricted to properly trained personnel; unqualified personnel are strictly cautioned against attempting repairs or adjustments not covered in this manual, at the risk of voiding the Warranty.

Read this manual thoroughly. A complete understanding of the characteristics and capabilities of this equipment will assure the dependable operation for which it was designed.

2T.02 General Description

Plasma torches are similar in design to the automotive spark plug. They consist of negative and positive sections separated by a center insulator. Inside the torch, the pilot arc starts in the gap between the negatively charged electrode and the positively charged tip. Once the pilot arc has ionized the plasma gas, the superheated column of gas flows through the small orifice in the torch tip, which is focused on the metal to be cut.

A single torch lead provides gas from a single source to be used as both the plasma and secondary gas. The air flow is divided inside the torch head. Single - gas operation provides a smaller sized torch and inexpensive operation.



CAUTION

Torch Leads are flexible but internal wires can be broken. Do not exceed a 2" radius bend and avoid repeated tight bends when possible.



NOTE!

Refer to Section "2T.05 Introduction to Plasma", for a more detailed description of plasma torch operation.


Refer to the Appendix Pages for additional specifications as related to the Power Supply used.

2T.03 Specifications

A. Torch Configurations


1. Hand/Manual Torch, Model SL60QD™

The hand torch head is at 75° to the torch handle. The hand torches include a torch handle and torch trigger assembly.



2. Mechanized Torch, Model

The standard machine torch has a positioning tube with rack & pinch block assembly.



B. Torch Leads Lengths

Hand Torches are available as follows:

- 20 ft / 6.1 m, with ATC connectors
- 50 ft / 15.2 m, with ATC connectors

Machine Torches are available as follows:

- 5 foot / 1.5 m, with ATC connectors
- 10 foot / 3.05 m, with ATC connectors
- 25 foot / 7.6 m, with ATC connectors
- 50 foot / 15.2 m, with ATC connectors

C. Torch Parts

Starter Cartridge, Electrode, Tip, Shield Cup

D. Parts - In - Place (PIP)

Torch Head has built - in switch 15 VDC circuit rating

E. Type Cooling

Combination of ambient air and gas stream through torch.

F. Torch Ratings

Manual Torch Ratings			
Ambient	104° F		
Temperature	40° C		
Duty Cycle	100% @ 60 Amps @ 400 scfh		
Maximum Current	60 Amps		
Voltage (V _{peak})	500V		
Arc Striking Voltage	500V		

Mechanized Torch Ratings			
Ambient	104° F		
Temperature	40° C		
Duty Cycle	100% @ 100 Amps @ 400 scfh		
Maximum Current	120 Amps		
Voltage (V _{peak})	500V		
Arc Striking Voltage	500V		

G. Gas Requirements

Manual and Mechanized Torch Gas Specifications				
Gas (Plasma and Secondary)	Compressed Air			
Operating Pressure Refer to NOTE	90 - 120 psi 6.2 - 8.3 bar			
Maximum Input Pressure	125 psi / 8.6 bar			
Gas Flow (Cutting and Gouging)	5 - 8.3 SCFM 300 - 500 scfh 142 - 235 lpm			



WARNING

This Torch is not to be used with oxygen (O_2) .

The SL60QD torch should not be used on an HF system.



NOTE!

Operating pressure varies with torch model, operating amperage, and torch leads length. Refer to gas pressure settings charts for each model..

H. Direct Contact Hazard

For standoff tip the recommended standoff is 3/16 inches / 4.7 mm.

2T.04 Quick Connection Torch

The new SL60QDTM (Quick Disconnect) torch allows for a quick change of the torch handle assembly from the leads. To change the torch handle assembly do the following.

- 1. Remove the torch handle assembly by grasping the torch handle in one hand and the coupler nut and leads in the other.
- 2. Rotate the nut a minimum of one full turn to the left (counter clockwise) and pull the torch handle assembly out from the leads in a straight line.
- 3. To reattach, grasp both as before and carefully align the internal connecting parts.
- 4. Carefully press the two together in a straight line.
- 5. Align the mark on the coupler nut with that on the top of the torch handle and rotate to the right (clockwise) drawing the two together and seating the connections inside. Do not use tools to tighten.

2T.05 Options And Accessories

For options and accessories, see Section 6.


2T.06 Introduction to Plasma

A. Plasma Gas Flow

Plasma is a gas which has been heated to an extremely high temperature and ionized so that it becomes electrically conductive. The plasma arc cutting and gouging processes use this plasma to transfer an electrical arc to the workpiece. The metal to be cut or removed is melted by the heat of the arc and then blown away.

While the goal of plasma arc cutting is separation of the material, plasma arc gouging is used to remove metals to a controlled depth and width.

In a Plasma Cutting Torch a cool gas enters Zone B, where a pilot arc between the electrode and the torch tip heats and ionizes the gas. The main cutting arc then transfers to the workpiece through the column of plasma gas in Zone C.



Typical Torch Head Detail

By forcing the plasma gas and electric arc through a small orifice, the torch delivers a high concentration of heat to a small area. The stiff, constricted plasma arc is shown in Zone C. Direct current (DC) straight polarity is used for plasma cutting, as shown in the illustration.

Zone A channels a secondary gas that cools the torch. This gas also assists the high velocity plasma gas in blowing the molten metal out of the cut allowing for a fast, slag - free cut.

B. Gas Distribution

The single gas used is internally split into plasma and secondary gases.

The plasma gas flows into the torch through the negative lead, through the starter cartridge, around the electrode, and out through the tip orifice.

The secondary gas flows down around the outside of the torch starter cartridge, and out between the tip and shield cup around the plasma arc.

C. Pilot Arc


When the torch is started a pilot arc is established between the electrode and cutting or gouging tip. This pilot arc creates a path for the main arc to transfer to the work.

D. Main Cutting Arc

DC power is also used for the main cutting arc. The negative output is connected to the torch electrode through the torch lead. The positive output is connected to the workpiece via the work cable and to the torch through a pilot wire.

E. Parts - In - Place (PIP)

The torch includes a 'Parts - In - Place' (PIP) circuit. When the shield cup is properly installed, it closes a switch. The torch will not operate if this switch is open.



Parts - In - Place Circuit Diagram for Hand Torch



This Page Intentionally Blank

SECTION 3 SYSTEM: INSTALLATION

3.01 Unpacking

- 1. Use the packing lists to identify and account for each item.
- 2. Inspect each item for possible shipping damage. If damage is evident, contact your distributor and / or shipping company before proceeding with the installation.
- 3. Record Power Supply and Torch model and serial numbers, purchase date and vendor name, in the information block at the front of this manual.

3.02 Lifting Options

The Power Supply includes handles for **hand lifting only.** Be sure unit is lifted and transported safely and securely.



WARNING

Do not touch live electrical parts.

Disconnect input power cord before moving unit.



FALLING EQUIPMENT can cause serious personal injury and can damage equipment.

HANDLES are not for mechanical lifting.

- Only persons of adequate physical strength should lift the unit.
- Lift unit by the handles, using two hands. Do not use straps for lifting.
- Use optional cart or similar device of adequate capacity to move unit.
- Place unit on a proper skid and secure in place before transporting with a fork lift or other vehicle.


3.03 Opening the Main Switch Cover

Systems are configured for and come with power cord connected for single phase or three phase configuration depending on system purchased. The input power switch is located on the rear panel along the top. To access the input locations, remove the screw at the top of the cover and flip down.



WARNING

Disconnect power before removing the cover.



Main Switch Cover

3.04 Primary Input Power Connections, SINGLE Phase




WARNING

Each CutMaster 60i system is a dedicated 1 Phase OR 3 Phase system and cannot be reconfigured to the other. Personal injury could occur if changing the phase is attempted..



CAUTION

The primary power source, fuse, and any extension cords used must conform to local electrical code and the recommended circuit protection and wiring requirements as specified in Section 2.



Single Phase Input Power Wiring

3.05 Primary Input Power Connections, THREE Phase




WARNING

Each CutMaster 60i system is a dedicated 1 Phase OR 3 Phase system and cannot be reconfigured to the other. Personal injury could occur if changing the phase is attempted..



CAUTION

The primary power source, fuse, and any extension cords used must conform to local electrical code and the recommended circuit protection and wiring requirements as specified in Section 2.



Three Phase Input Power Wiring



NOTE!

As long as the power supply is connected to input power ranging from 208 VAC to 480 VAC, the system will automatically detect this and run accordingly.

3.06 Gas Connections

Connecting Gas Supply to Unit


The connection is the same for compressed air or high pressure cylinders. Refer to the following two subsections if an optional air line filter is to be installed.

1. Connect the air line to the inlet port. The illustration shows typical fittings as an example.



NOTE!

For a secure seal, apply thread sealant to the fitting threads, according to manufacturer's instructions. Do not use Teflon tape as a thread sealer, as small particles of the tape may break off and block the small air passages in the torch.





NOTE!

Filter replacement part numbers can be found in Section 6 of this manual

Installing Optional Single - Stage Air Filter


An optional filter kit (7-7507) is recommended for improved filtering with compressed air, to keep moisture and debris out of the torch.

- 1. Attach the Single Stage Filter Hose to the Inlet Port 1/4" NPT of the system filter.
- 2. Attach the Filter Assembly to the filter hose.
- 3. Connect the air line to the Filter using the 1/4" NPT. The illustration shows typical fittings as an example.



NOTE!

For a secure seal, apply thread sealant to the fitting threads, according to manufacturer's instructions. Do not use Teflon tape as a thread sealer, as small particles of the tape may break off and block the small air passages in the torch.



Optional Single - Stage Filter Installation



NOTE!

Filter replacement part numbers can be found in Section 6 of this manual

Installing Optional Two - Stage Air Filter Kit

This optional two - stage air line filter (9-9387) is also for use on compressed air shop systems. Filter removes moisture and contaminants to at least 5 microns.

Connect the air supply as follows:


1. Attach the Two Stage Filter bracket to the back of the power supply with the screws supplied.



NOTE!

For a secure seal, apply thread sealant to the fitting threads, according to manufacturer's instructions. Do not use Teflon tape as a thread sealer, as small particles of the tape may break off and block the small air passages in the torch.

- 2. Connect the two stage filter outlet hose to the inlet port of the Regulator / Filter Assembly.
- 3. Use customer supplied fittings to connect the air line to the Filter. A 5/16 (8mm) O.D. smooth tubing should be used with the press in fitting.



Optional Two - Stage Filter Installation



NOTE!

Filter replacement part numbers can be found in Section 6 of this manual

Using High Pressure Air Cylinders

When using high pressure air cylinders as the air supply:

- 1. Refer to the manufacturer's specifications for installation and maintenance procedures for high pressure regulators.
- 2. Examine the cylinder valves to be sure they are clean and free of oil, grease or any foreign material. Briefly open each cylinder valve to blow out any dust which may be present.
- 3. The cylinder must be equipped with an adjustable high pressure regulator capable of outlet pressures up to 120 psi (8.3 bar) maximum and flows of least 300-500 scfh / 5 8.3 CFM (142-235 lpm).
- 4. Connect supply hose to the cylinder.




NOTE!

Pressure should be set at 120 psi (8.3 bar) at the high pressure cylinder regulator.

3.07 Work Lead Connections

Connect the Work Lead to the power supply and the work piece.

- 1. Attache the Dinse type connection of the work lead to the power supply front panel as shown below. Push in and turn clockwise to the right until tight.
- 2. Connect the work clamp to the workpiece or cutting table. The area must be free from oil, paint and rust. Connect only to the main part of the work piece; do not connect to the part to be cut off.





This Page Intentionally Blank

SECTION 3 TORCH: INSTALLATION

3T.01 Torch Connections


If necessary, connect the torch to the Power Supply. Connect only the ESAB model SL60, SL60QDTM or SL100 / Mechanical Torch to this power supply. Maximum torch leads length is 100 feet / 30.5 m, including extensions.



WARNING

Disconnect primary power at the source before connecting the torch.

- Align the ATC male connector (on the torch lead) with the female receptacle. Push the male connector into the female receptacle. The connectors should push together with a small amount of pressure.
- 2. Secure the connection by turning the locking nut clockwise until it clicks. DO NOT use the locking nut to pull the connection together. Do not use tools to secure the connection.



Connecting the Torch to the Power Supply

3. The system is ready for operation.

Check Air Quality

To test the quality of air:

1. Put the ON / OFF switch in the ON (Left) position.



3. Place a welding filter lens in front of the torch and turn ON the air. **Do not start an arc!** Any oil or moisture in the air will be visible on the lens.

3T.02 Setting Up Mechanical Torch




WARNING

Disconnect primary power at the source before disassembling the torch or torch leads.

The mechanical torch includes a positioning tube with rack and pinch block assembly.

- 1. Mount the torch assembly on the cutting table.
- 2. To obtain a clean vertical cut, use a square to align the torch perpendicular to the surface of the workpiece.



Mechanical Torch Set - Up

3. The proper torch parts (shield cup, tip, start cartridge, and electrode) must be installed for the type of operation. Refer to Section "4T.01 Torch Parts Selection" on page 4T-1 for details.




This Page Intentionally Blank

SECTION 4 SYSTEM: OPERATION

4.01 Front Panel Controls / Features

See Illustration for numbering Identification





Numeric Display

- Displays software revision at start up
- Displays amperage values (Factory default)
- Displays error codes
- Displays pre-set (preview) maintenance functions

2. AC Indicator

Steady light indicates power supply is ready for operation. Blinking light indicates the input voltage is outside of operating range or internal fault.

3. --- DC Indicator

Indicator is ON when DC output circuit is active.



Indicator is ON when unit is in "Latch" mode.

CUTMASTER 60i

5. Set Mode Indicator

Indicator is ON when unit is flowing gas and pressure can be set.

6. Shield Cup In Place Indicator

Indicator is Blinking when any of the following are not in place or connected: Shield Cup, ATC leads or Quick Disconnect.



7. Gouge Mode Indicator

Indicator is ON when unit is in "Gouge" mode and all Cutting Indicators (#8) are illuminated.

8. Type of Cutting Indicator

Different segments will be illuminated to indicate different types of cutting.

- Gouging All illuminated
- Normal Cutting and Latch Mode Center indicator will be off.
- RAR (Rapid Auto Restart) Cutting Every other indicator will be off.
- Set Mode All indicators will be off.

9. Tault Indicator

Indicator is ON when unit is in fault condition. See error codes appendix for fault light explanations. Flashing when active.

Factory default: Off



EOL (End Of Life) Indicator

Indicator is normally off. It is also off during Drag Cutting.

When on it is to inform user that consumable failure is imminent

Active and/or operable in all cutting modes except Drag..

11. Over Temp Indicator

Indicator is normally OFF. Indicator is ON/FLASHING when internal temperature exceeds normal limits. Let the unit cool before continuing operation.



Gas Pressure Indicator

Indicator used to show low, optimal and high gas pressure. Torch type, lead length, cutting mode and amperage should all be set prior to setting the gas pressure. (90 - 125 PSI / 6.2 - 8.6 bar)

One of 7 segments will always be on when unit is on. The gas bottle will be illuminated and flash during a gas pressure fault. Bottle will flash when pressure is below a minimum threshold. Bottle will be on continuously when acceptable.

Factory default: One, or two segments and gas bottle will be illuminated depending on the gas pressure level. The green indicator in the middle indicates the recommended pressure for the process (Amps, torch type, lead length). Different processes have different optimum pressures.

Yellow indicates above or below optimum pressure and red indicates unacceptable pressure for good cutting. Each LED represents 5 psi. Two adjacent LEDs will represent a value in between the two or 2.5 lb. pressure change..

13. Gas Pressure Selector

Rotate the lower knob to set the gas pressure.

14. SL60 SL100 SLV Torch Type Indicator

Used for selecting one of the three torch options and torch length for each. SLV will be automatically detected.

Factory default: On, SL60 which includes SL60QDTM (Quick Disconnect)

Press and release the lower knob without rotating it to step through selection of torch type.



NOTE


If you have gone past the desired setting, you will need to continue to step through all the other torch types and lengths to get back to return to it..

15. Lead Length Indicator

Used for selecting torch lead length for each torch type ranging between 20' and 100' leads.

Factory default: On, 20'

Press and release the lower knob without rotating it to step through selection of torch type followed by lead length.





NOTE!

If you have gone past the desired setting, you will need to continue to step through all the other torch types and lengths to get back to return to it..

CUTMASTER 60i

16. Upper Knob - Amp and Mode Selector

Rotate knob to increase or decrease amperage. Indicator A is ON when numeric display is showing amperage output.

Press and release knob without turning to step through the different Modes.

Factory default: On

Numeric display **5 1** A

17. Torch Quick Disconnect Receptacle

Torch Leads are connected here by aligning the connectors, pressing in and turning locking ring clockwise-to-the-right to secure. Connection should only be snug with no tools used.

18. Work Lead Dinse type receptacle

Align Dinse type connector on work lead with receptacle, press in and turn clockwise to the right until tight.

4.02 Preparations for Operation

At the start of each operating session:



WARNING

Disconnect primary power at the source before assembling or disassembling power supply, torch parts, or torch and leads assemblies.

Torch Parts Selection

Check the torch for proper assembly and appropriate torch parts. The torch parts must correspond with the type of operation, and with the amperage output of this Power Supply (60 amps maximum). Refer to Section 4T.07 and following for torch parts selection.

Torch Connection

Check that the torch is properly connected. Only Thermal Dynamics models SL60, SL60QD™ / Manual or SL100 / Mechanical Torches may be connected to this Power Supply. See Section 3T of this manual.

Check Primary Input Power Source


- 1. Check the power source for proper input voltage. Make sure the input power source meets the power requirements for the unit per Section 2, Specifications.
- 2. Connect the input power cable (or close the main disconnect switch) to supply power to the system.

Air Source

Ensure source meets requirements (refer to Section 2). Check connections and turn air supply ON.

Connect Work Cable

Clamp the work cable to the workpiece or cutting table. The area must be free from oil, paint and rust. Connect only to the main part of the workpiece; do not connect to the part to be cut off.



Power ON

Place the Power Supply ON / OFF switch to the ON (right) position. AC indicator \sim turns ON. The Control Board performs several tests to determine the system is ready to operate. During the self-tests the

digital display first shows (revision) followed by the firmware revision number which includes decimals. 1.1.0 is an example of a production released code revision that may be displayed.

Next displayed is the "checksum" a combination of letters and numbers that are unique to the firmware revision. These are used by service personal to determine if the firmware has been corrupted.

If there are no issues detected the output current setting will be displayed with the letter "A" to the right, showing the output current setting. Should a problem be detected the fault code in the format Exxx will display and the "A" will not be illuminated. Refer to Section 5.04 for fault code explanations.

Gas indicator turns ON if there is sufficient gas pressure for power supply operation and the cooling fan turns ON. (90 - 125 PSI / 6.2 - 8.6 bar)




NOTE!


Minimum pressure for power supply operation is lower than minimum for torch operation.


The cooling fan will turn ON as soon as the unit is turned ON. After a short amount of time the fan switches to low speed. The fan will return to high speed as soon as the torch switch (Start Signal) is activated or if the unit is turned OFF, then turned ON again. If an over temperature condition occurs, the fan will continue to run at high speed while the condition exists and for a five (5) minute period once the condition is cleared.

Select Cutting Mode



1. Press and release the upper knob without turning to enter the mode selection menu. Place the system in one of the four cutting modes available by pressing and releasing the knob until you reach the desired mode.:





2. After selecting the cutting mode, set the output current by turning the knob.

Set Torch Parameters

1. Press and release the bottom knob without rotating to enter the torch type and leads length selections.

Set Operating Pressure



NOTE!

Before the gas pressure is set, the torch type, leads length, type of cutting and amperage should all be set as they will affect the pressures required. If any of those are changed, the pressure should be checked again to make sure it is optimized.

- 1. Gas pressure must be set in the cutting mode to be used, not in the SET/PURGE mode. Each mode may require a different pressure for optimal cutting. (90 125 PSI / 6.2 8.6 bar)
- 2. Set the gas pressure/flow using the lower knob, 2. Changes will show on the Gas Pressure Interlock The green indicator in the center is the ideal setting. Each indicator when lit separately is equal to 5 lbs. from the segment next to it. Each will show 5, 10 or 15 lbs or more below or above the ideal. When two segments are illuminated together then the change is half as much or 2.5 lbs.. The pressure settings will all be affected by the other settings for torch, torch length and type of cutting and will require adjustments to the pressure setting.

Cutting Operation

When the torch leaves the workpiece during cutting operations in the RUN mode, there is a brief delay in restarting the pilot arc. With the system in the RAPID AUTO RESTART mode, when the torch leaves the workpiece the pilot arc restarts instantly, and the cutting arc restarts instantly when the pilot arc contacts the workpiece. (Use the 'Rapid Auto Restart' mode when cutting expanded metal or gratings, or trimming operations when an uninterrupted restart is desired).

With the system in the LATCH mode the main cutting arc will be maintained after the torch switch is released. To exit or cancel the LATCH mode, press and release the trigger again or lift the torch from the cutting surface so the arc goes out.

Typical Cutting Speeds

Cutting speeds vary according to torch output amperage, the type of material being cut, and operator skill. Refer to Section "4T.08 Recommended Cutting Speeds for Mechanized Torch With Exposed Tip" and following for greater details.

Output current setting or cutting speeds may be reduced to allow slower cutting when following a line, or using a template or cutting guide while still producing cuts of excellent quality.

Postflow

Release the trigger to stop the cutting arc. Gas continues to flow for approximately 20 seconds. During post-flow, if the user moves the trigger release to the rear and presses the trigger, the pilot arc starts. The main arc transfers to the workpiece if the torch tip is within transfer distance to the workpiece.

Shutdown

Turn the ON / OFF switch to OFF, to the left as you face the unit from the rear. After a short delay all Power Supply indicators and fan shut OFF. Unplug the input power cord or disconnect input power. Power is removed from the system.



NOTE!

To maximize the longevity of the internal electronics, allow the power supply to continue running (without cutting) until the cooling fan speed changes to slow. This may take a few minutes



This Page Intentionally Blank

SECTION 4 TORCH: OPERATION

4T.01 Torch Parts Selection

Depending on the type of operation to be done determines the torch parts to be used.

Type of operation:

Drag cutting, standoff cutting or gouging

Torch parts:

Shield Cup, Cutting Tip, Electrode and Start Cartridge



NOTE!

Refer to Section 4T.07 and following for additional information on torch parts.

Change the torch parts for a different operation as follows:



WARNING


Disconnect primary power at the source before assembling or disassembling torch parts, or torch and leads assemblies.



NOTE!

The shield cup holds the tip and start cartridge in place. Position the torch with the shield cup facing upward to keep these parts from falling out when the cup is removed.

- 1. Unscrew and remove the shield cup assembly from the torch head.
- 2. Remove the Electrode by pulling it straight out of the Torch Head.



- 3. Install the replacement Electrode by pushing it straight into the torch head until it clicks.
- 4. Install the start cartridge and desired tip for the operation into the torch head.
- 5. Hand tighten the shield cup assembly until it is seated on the torch head. If resistance is felt when installing the cup, check the threads before proceeding.


4T.02 Cut Quality



NOTE!

Cut quality depends heavily on setup and parameters such as torch standoff, alignment with the workpiece, cutting speed, gas pressures, and operator ability.

Cut quality requirements differ depending on application. For instance, nitride build - up and bevel angle may be major factors when the surface will be welded after cutting. Dross - free cutting is important when finish cut quality is desired to avoid a secondary cleaning operation. The following cut quality characteristics are illustrated in the following figure:



Cut Surface

The desired or specified condition (smooth or rough) of the face of the cut.

Nitride Build - Up

Nitride deposits can be left on the surface of the cut when nitrogen is present in the plasma gas stream. These buildups may create difficulties if the material is to be welded after the cutting process.

Bevel Angle

The angle between the surface of the cut edge and a plane perpendicular to the surface of the plate. A perfectly perpendicular cut would result in a 0° bevel angle.

Top - Edge Rounding

Rounding on the top edge of a cut due to wearing from the initial contact of the plasma arc on the workpiece.

Bottom Dross Buildup

Molten material which is not blown out of the cut area and resolidifies on the plate. Excessive dross may require secondary cleanup operations after cutting.

Kerf Width

The width of the cut (or the width of material removed during the cut).

Top Spatter (Dross)

Top spatter or dross on the top of the cut caused by slow travel speed, excess cutting height, or cutting tip whose orifice has become elongated.

4T.03 General Cutting Information



WARNING

Disconnect primary power at the source before disassembling the power supply, torch, or torch leads.



Frequently review the Important Safety Precautions at the front of this manual. Be sure the operator is equipped with proper gloves, clothing, eye and ear protection. Make sure no part of the operator's body comes into contact with the workpiece while the torch is activated.



CAUTION

Sparks from the cutting process can cause damage to coated, painted, and other surfaces such as glass, plastic and metal.



NOTE!

Handle torch leads with care and protect them from damage.

Piloting

Piloting is harder on parts life than actual cutting because the pilot arc is directed from the electrode to the tip rather than to a workpiece. Whenever possible, avoid excessive pilot arc time to improve parts life.

Torch Standoff


Improper standoff (the distance between the torch tip and workpiece) can adversely affect tip life as well as shield cup life. Standoff may also significantly affect the bevel angle. Reducing standoff will generally result in a more square cut.

Edge Starting

For edge starts, hold the torch perpendicular to the workpiece with the front of the tip near (not touching) the edge of the workpiece at the point where the cut is to start. When starting at the edge of the plate, do not pause at the edge and force the arc to "reach" for the edge of the metal. Establish the cutting arc as quickly as possible.

Direction of Cut

In the torches, the plasma gas stream swirls as it leaves the torch to maintain a smooth column of gas. This swirl effect results in one side of a cut being more square than the other. Viewed along the direction of travel, the right side of the cut is more square than the left.



Side Characteristics Of Cut

To make a square - edged cut along an inside diameter of a circle, the torch should move counterclockwise around the circle. To keep the square edge along an outside diameter cut, the torch should travel in a clockwise direction.

Dross

When dross is present on carbon steel, it is commonly referred to as either "high speed, slow speed, or top dross". Dross present on top of the plate is normally caused by too great a torch to plate distance. "Top dross" is normally very easy to remove and can often be wiped off with a welding glove. "Slow speed dross" is normally present on the bottom edge of the plate. It can vary from a light to heavy bead, but does not adhere tightly to the cut edge, and can be easily scraped off. "High speed dross" usually forms a narrow bead along the bottom of the cut edge and is very difficult to remove. When cutting a troublesome steel, it is sometimes useful to reduce the cutting speed to produce "slow speed dross". Any resultant cleanup can be accomplished by scraping, not grinding.

4T.04 Hand Torch Operation

Standoff Cutting With Hand Torch



NOTE!

For best performance and parts life, always use the correct parts for the type of operation.

1. The torch can be comfortably held in one hand or steadied with two hands. Position the hand to press the Trigger on the torch handle. With the hand torch, the hand may be positioned close to


the torch head for maximum control or near the back end for maximum heat protection. Choose the holding technique that feels most comfortable and allows good control and movement.




NOTE!

The tip should never come in contact with the workpiece except during drag cutting operations.

- 2. Depending on the cutting operation, do one of the following:
 - a. For edge starts, hold the torch perpendicular to the workpiece with the front of the tip on the edge of the workpiece at the point where the cut is to start.
 - b. For **standoff cutting**, hold the torch 1/8 3/8 in (3-9 mm) from the workpiece as shown below.



- 3. Hold the torch away from your body.
- 4. Slide the trigger release toward the back of the torch handle while simultaneously squeezing the trigger. The pilot arc will start.




5. Bring the torch within transfer distance to the work. The main arc will transfer to the work, and the pilot arc will shut OFF.



NOTE!

The gas preflow and postflow are a characteristic of the power supply and not a function of the torch.




- 6. Cut as usual. Simply release the trigger assembly to stop cutting.
- 7. Follow normal recommended cutting practices as provided in the power supply operator's manual.



NOTE!

When the shield cup is properly installed, there is a slight gap between the shield cup and the torch handle. Gas vents through this gap as part of normal operation. Do not attempt to force the shield cup to close this gap. Forcing the shield cup against the torch head or torch handle can damage components.

8. For a consistent standoff height from the work-piece, install the standoff guide by sliding it onto the torch shield cup. Install the guide with the legs at the sides of the shield cup body to maintain good visibility of the cutting arc. During operation, position the legs of the standoff guide against the workpiece.




Shield Cup With Straight Edge

The drag shield cup can be used with a non conductive straight edge to make straight cuts by hand.



WARNING

The straight edge must be non - conductive.



Using Drag Shield Cup With Straight Edge

The crown shield cup functions best when cutting 3/16 inch (4.7 mm) solid metal with relatively smooth surface.

Drag Cutting With a Hand Torch


Drag cutting works best on metal 1/4" (6 mm) thick or less.



NOTE!

For best parts performance and life, always use the correct parts for the type of operation

- 1. Install the drag cutting tip and set the output current.
- 2. The torch can be comfortably held in one hand or steadied with two hands. Position the hand to press the Trigger on the torch handle. With the hand torch, the hand may be positioned close to the torch head for maximum control or near the back end for maximum heat protection. Choose the holding technique that feels most comfortable and allows good control and movement.
- 4. Keep the torch in contact with the workpiece during the cutting cycle.
- 5. Hold the torch away from your body.
- 6. Slide the trigger release toward the back of the torch handle while simultaneously squeezing the trigger. The pilot arc will start.




7. Bring the torch within transfer distance to the work. The main arc will transfer to the work, and the pilot arc will shut OFF.



NOTE!

The gas preflow and postflow are a characteristic of the power supply and not a function of the torch.



8. Cut as usual. Simply release the trigger assembly to stop cutting.

9. Follow normal recommended cutting practices as provided in the power supply operator's manual.



NOTE!

When the shield cup is properly installed, there is a slight gap between the shield cup and the torch handle. Gas vents through this gap as part of normal operation. Do not attempt to force the shield cup to close this gap. Forcing the shield cup against the torch head or torch handle can damage components.

Piercing With Hand Torch


1. The torch can be comfortably held in one hand or steadied with two hands. Position the hand to press the Trigger on the torch handle. With the hand torch, the hand may be positioned close to the torch head for maximum control or near the back end for maximum heat protection. Choose the technique that feels most comfortable and allows good control and movement.



NOTE!

The tip should never come in contact with the workpiece except during drag cutting operations.

- 2. Angle the torch slightly to direct blowback particles away from the torch tip (and operator) rather than directly back into it until the pierce is complete.
- 3. In a portion of the unwanted metal start the pierce off the cutting line and then continue the cut onto the line. Hold the torch perpendicular to the workpiece after the pierce is complete.
- 4. Hold the torch away from your body.
- 5. Slide the trigger release toward the back of the torch handle while simultaneously squeezing the trigger. The pilot arc will start.



6. Bring the torch within transfer distance to the work. The main arc will transfer to the work, and the pilot arc will shut OFF.



NOTE!

The gas preflow and postflow are a characteristic of the power supply and not a function of the torch.

When the shield cup is properly installed, there is a slight gap between the shield cup and the torch handle. Gas vents through this gap as part of normal operation. Do not attempt to force the shield cup to close this gap. Forcing the shield cup against the torch head or torch handle can damage components.

7. Clean spatter and scale from the shield cup and the tip as soon as possible. Spraying the shield cup in anti - spatter compound will minimize the amount of scale which adheres to it.

Cutting speed depends on material, thickness, and the operator's ability to accurately follow the desired cut line. The following factors may have an impact on system performance:

- Torch parts wear
- Air quality
- Line voltage fluctuations
- Torch standoff height
- Proper work cable connection

4T.05 Gouging



WARNING

Be sure the operator is equipped with proper gloves, clothing, eye and ear protection and that all safety precautions at the front of this manual have been followed. Make sure no part of the operator's body comes in contact with the workpiece when the torch is activated.

Disconnect primary power to the system before disassembling the torch, leads, or power supply.



CAUTION

Sparks from plasma gouging can cause damage to coated, painted or other surfaces such as glass, plastic, and metal. Check torch parts. The torch parts must correspond with the type of operation. Refer to Section 4T.07. Torch Parts Selection.

Gouging Parameters

Gouging performance depends on parameters such as torch travel speed, current level, lead angle (the angle between the torch and workpiece), and the distance between the torch tip and workpiece (standoff).



CAUTION

Touching the torch tip or shield cup to the work surface will cause excessive parts wear.

Torch Travel Speed



NOTE!

Refer to Appendix Pages for additional information as related to the Power Supply used.


Optimum torch travel speed is dependent on current setting, lead angle, and mode of operation (hand or machine torch).

Current Setting

Current settings depend on torch travel speed, mode of operation (hand or machine torch), and the amount of material to be removed.

Lead Angle

The angle between the torch and workpiece depends on the output current setting and torch travel speed. The recommended lead angle is 35°. At a lead angle greater than 45° the molten metal will not be blown out of the gouge and may be blown back onto the torch. If the lead angle is too small (less than 35°), less material may be removed, requiring more passes. In some applications, such as removing welds or working with light metal, this may be desirable.



A-00941 AB

Gouging Angle and Standoff Distance

Standoff Distance

The tip to work distance affects gouge quality and depth. Standoff distance of 1/8 - 1/4 inch (3 - 6 mm) allows for smooth, consistent metal removal. Smaller standoff distances may result in a severance cut rather than a gouge. Standoff distances greater than 1/4 inch (6 mm) may result in minimal metal removal or loss of transferred main arc.

Slag Buildup

Slag generated by gouging on materials such as carbon and stainless steels, nickels, and alloyed steels, can be removed easily in most cases. Slag does not obstruct the gouging process if it accumulates to the side of the gouge path. However, slag build - up can cause inconsistencies and irregular metal removal if large amounts of material build up in front of the arc. The build - up is most often a result of improper travel speed, lead angle, or standoff height.

4T.06 Mechanized Torch Operation

Cutting With Mechanized Torch

The mechanized torch can be activated by remote control pendant or by a remote interface device such as CNC.

1. To start a cut at the plate edge, position the center of the torch along the edge of the plate.

Travel Speed

Proper travel speed is indicated by the trail of the arc which is seen below the plate. The arc can be one of the following:

1. Straight Arc


A straight arc is perpendicular to the workpiece surface. This arc is generally recommended for the best cut using air plasma on stainless or aluminum.

2. Leading Arc

The leading arc is directed in the same direction as torch travel. A five degree leading arc is generally recommended for air plasma on mild steel.

3. Trailing Arc

The trailing arc is directed in the opposite direction as torch travel.



Mechanized Torch Operation

For optimum smooth surface quality, the travel speed should be adjusted so that only the leading edge of the arc column produces the cut. If the travel speed is too slow, a rough cut will be produced as the arc moves from side to side in search of metal for transfer.


Travel speed also affects the bevel angle of a cut. When cutting in a circle or around a corner, slowing down the travel speed will result in a squarer cut. The power source output should be reduced also. Refer to the appropriate Control Module Operating Manual for any Corner Slowdown adjustments that may be required.

Piercing With Machine Torch

To pierce with a machine torch, the arc should be started with the torch positioned as high as possible above the plate while allowing the arc to transfer and pierce. This standoff helps avoid having molten metal blow back onto the front end of the torch.

When operating with a cutting machine, a pierce or dwell time is required. Torch travel should not be enabled until the arc penetrates the bottom of the plate. As motion begins, torch standoff should be reduced to the recommended 1/8 - 1/4 inch (3-6 mm) distance for optimum speed and cut quality. Clean spatter and scale from the shield cup and the tip as soon as possible. Spraying or dipping the shield cup in anti - spatter compound will minimize the amount of scale which adheres to it.

4T.07 Parts Selection for Manual and Mechanized Torch Cutting



Art # A-13147_AC

4T.08 Recommended Cutting Speeds With Exposed Tip

	Cu	ıtMaster@	60i Wi	th Exposed	Tip					Type N	laterial:	Mild Ste	el		
		Type	Plasma	Gas: Air					Type So	econda	ry Gas:	Single (Gas Torc	h	
Thick	ness	Tip	Output	Amperage		d (Per lute)	Stand	loff	Plasm Press		Flow (SCFH)	Pierce	Pierce Height	
Inches	mm	(Cat. No.)	Volts (VDC)	(Amps)	Inches	Meters	Inches	mm	psi	bar	Plasma	Total**	Delay (Sec)	Inches	mm
0.036	0.9	9-8208	104	40	340	8.64	0.19 4.8				55	170	0.00	0.2	5.1
0.06	1.5	9-8208	108	40	250	6.35	0.19	4.8	Set to	n the	55	170	0.10	0.2	5.1
0.075	1.9	9-8208	108	40	190	4.83	0.19	4.8	cen		55	170	0.30	0.2	5.1
0.135	3.4	9-8208	110	40	105	2.67	0.19	4.8	regio		55	170	0.40	0.2	5.1
0.188	4.8	9-8208	113	40	60	1.52	0.19	4.8	the production that the thick the th		55	170	0.60	0.2	5.1
0.25	6.4	9-8208	111	40	40	1.02	0.19	4.8	illumi		55	170	1.00	0.2	5.1
0.375	9.5	9-8208	124	40	21	0.53	0.19	4.8	green		55	170	NR	NR	NR
0.500	12.7	9-8208	123	40	11	0.28	0.19	4.8	seled	cted.	55	170	NR	NR	NR
0.625	15.9	9-8208	137	40	7	0.18	0.19	4.8			55	170	NR	NR	NR

	Cu	tMaster@	60i Wit	th Exposed	Тір				Тур	e Mat	erial: Sta	inless S	teel		
		Type I	Plasma	Gas: Air				1	Type Se	conda	ry Gas:	Single G	as Torcl	1	
Thickn	Thickness Tip Output Amperage Speed (Per Minute)							doff	Plasm Press		Flow (SCFH)	Pierce	Pierce Height	
Inches	mm	(Cat. No.)	Volts (VDC)	(Amps)	Inches	Meters	Inches	mm	psi	bar	Plasma	Total**	Delay (Sec)	Inches	mm
0.036	0.9	9-8208	103	40	355	9.02	0.125	3.2			55	170	0.00	0.2	5.1
0.05	1.3	9-8208	98	40	310	7.87	0.125	3.2	Set to		55	170	0.00	0.2	5.1
0.06	1.5	9-8208	98	40	240	6.10	0.125	3.2	cen regio		55	170	0.10	0.2	5.1
0.078	2.0	9-8208	100	40	125	3.18	0.125	3.2	the pre		55	170	0.30	0.2	5.1
0.135	3.4	9-8208	120	40	30	0.76	0.187	4.8	dial. T		55	170	0.40	0.2	5.1
0.188	4.8	9-8208	124	40	20	0.51	0.187	4.8	illumii green		55	170	0.60	0.2	5.1
0.25	6.4	9-8208	122	40	15	0.38	0.187	4.8	selec		55	170	1.00	0.2	5.1
0.375	9.5	9-8208	126	40	10	0.25	0.187	4.8			55	170	NR	NR	NR

CUTMASTER 60i

	Cu	tMaster@	60i Wi	th Exposed	l Tip				1	Гуре М	aterial: A	luminur	n		
		Туре	Plasma	Gas: Air					Type Se	conda	ry Gas: S	Single G	as Torch		
Thick	ness	Tip	Output	Amperage		d (Per lute)	Stan	doff	Plasma Press		Flow (SCFH)	Pierce	Pierce Height	
Inches	mm	(Cat. No.)	Volts (VDC)	(Amps)	Inches	Meters	Inches mm psi		psi	bar	Plasma	Total**	Delay (Sec)	Inches	mm
0.032	0.8	9-8208	110	40	440	11.18	0.187	4.8			55	170	0.00	0.2	5.1
0.051	1.3	9-8208	109	40	350	8.89	0.187	4.8	Set to		55	170	0.10	0.2	5.1
0.064	1.6	9-8208	112	40	250	6.35	0.187	4.8	cen regio		55	170	0.10	0.2	5.1
0.079	2.0	9-8208	112	40	200	5.08	0.19	4.8	the pre		55	170	0.30	0.2	5.1
0.125	3.2	9-8208	118	40	100	2.54	0.19	4.8	dial. T		55	170	0.40	0.2	5.1
0.188	4.8	9-8208	120	40	98	2.49	0.187	4.8	illumir green		55	170	0.60	0.2	5.1
0.250	6.4	9-8208	123	40	50	1.27	0.187	4.8	selec		55	170	1.00	0.2	5.1
0.375	9.5	9-8208	134	40	16	0.41	0.187	4.8			55	170	NR	NR	NR

	C	utMaster	® 60i W	ith Exposed	l Tip					Type N	laterial: N	/lild Stee	I		
		Туре	Plasma	Gas: Air					Type Se	econda	ry Gas: S	Single Ga	s Torch		
Thick	ness	Tip	Output	Amperage		d (Per nute)	Stand	off	Plasma Press		Flow (SCFH)	Pierce	Pierce H	leight
Inches	mm	(Cat. No.)	Volts (VDC)	(Amps) Inches Meters Inches mm ps 60 290 7.37 0.19 4.8						bar	Plasma	Total**	Delay (Sec)	Inches	mm
0.060	1.5	9-8210	110 60 290 7.37 0.19 4.8 120 60 285 7.24 0.19 4.8								90	245	0.00	0.19	4.8
0.075	1.9	9-8210	 								90	245	0.10	0.19	4.8
0.120	3.0	9-8210									90	245	0.10	0.19	4.8
0.135	3.4	9-8210	119	60	170 432 019 48				Set to	the	90	245	0.10	0.19	4.8
0.188	4.8	9-8210	121	60	100	2.54	0.19	4.8	cent		90	245	0.20	0.19	4.8
0.250	6.4	9-8210	119	60	80	2.03	0.19	4.8	regio		90	245	0.30	0.19	4.8
0.375	9.5	9-8210	124	60	50	1.27	0.19	4.8	the pre dial. T		90	245	0.50	0.19	4.8
0.500	12.7	9-8210	126	60	26	0.66	0.19	4.8	illumir		90	245	0.75	0.19	4.8
0.625	15.9	9-8210	127	60	19	0.48	0.19	4.8	green		90	245	Rol	ling Pierce	е
0.750	19.1	9-8210	134	60	0.19	4.8	selec	ted.	90	245	Rol	ling Pierce	е		
1.000	25.4	9-8210	0 140 60 6 0.15 0.19								90	245	Rol	ling Pierce	е
1.250	31.8	9-8210		NR, n	nanual cu	tting only					90	245		NR	
1.500	38.1	9-8210		NR, n	nanual cu	tting only					90	245		NR	

	Cu	ıtMaster®	60i Wit	h Exposed	Tip				Туре	Mater	ial: Stain	less Ste	el		
		Type P	Plasma (Gas: Air				Ty	ype Seco	ondary	Gas: Sir	ngle Gas	Torch		
Thick	ness	Tip	Output	Amperage		d (Per iute)	Stand	loff	Plasma Press		Flow (SCFH)	Pierce	Pier Heig	
Inches	mm	(Cat. No.)	Volts (VDC)	(Amps)	Inches	Meters	Inches	mm	psi	bar	Plasma	Total**	Delay (Sec)	Inches	mm
0.06	1.5	9-8210	119	60	350	8.91	0.19	4.8			90	245	0.00	0.20	5.1
0.075	1.9	9-8210	116	60	300	7.64	0.19	4.8			90	245	0.10	0.20	5.1
0.120	3.0	9-8210	123	60	150	3.82	0.19	4.8			90	245	0.10	0.20	5.1
0.135	3.4	9-8210	118	60	125	3.18	0.19	4.8	Set to		90	245	0.10	0.20	5.1
0.188	4.8	9-8210	122	60	90	2.29	0.19	4.8	cent regio		90	245	0.20	0.20	5.1
0.250	6.4	9-8210	120	60	65	1.65	0.19	4.8	the pre		90	245	0.30	0.20	5.1
0.375	9.5	9-8210	130	60	30	0.76	0.19	4.8	dial. Ti		90	245	0.50	0.20	5.1
0.500	12.7	9-8210	132	60	21	0.53	0.19	4.8	illumir green		90	245	0.75	0.20	5.1
0.625	15.9	9-8210	130	60	15	0.38	0.19	4.8	selec		90	245	Roll	ing Pierc	е
0.750	19.1	9-8210	142	60	12	0.31	0.25	6.4			90	245	Roll	ing Pierc	е
1.000	25.4	9-8210		NR,	manual c	cutting on	ly				90	245	Roll	ing Pierc	е
1.250	31.8	9-8210		NR,	manual c	cutting on	ly				90	245		NR	

	Cut	tMaster®	60i Wi	th Exposed	Tip				Т	уре Ма	aterial: A	luminum	1		
		Туре	Plasma	Gas: Air					Type Se	condar	y Gas: S	ingle Ga	s Torch		
Thick	iness	Tip	Output	Amperage		d (Per lute)	Stan	doff	Plasma Press		Flow (SCFH)	Pierce	Pierce Height	
Inches	mm	(Cat. No.)	Volts (VDC)	(Amps)	Inches	Meters	Inches	mm	psi	bar	Plasma	Total**	Delay (Sec)	Inches	mm
0.060	1.5	9-8210	110	60	0.25	6.4	Set to	the	90	245	0.00	0.25	6.4		
0.075	1.9	9-8210	110	60	440	11.18	0.25	6.4	cent regio		90	245	0.10	0.25	6.4
0.120	3.0	9-8210	116	60	250	6.35	0.25	6.4	the pre		90	245	0.10	0.25	6.4
0.188	3.4	9-8210	116	60	170	4.32	0.25	6.4	dial. T		90	245	0.20	0.25	6.4
0.250	6.4	9-8210	132	60	85	2.16	0.25	6.4	illumir green		90	245	0.30	0.25	6.4
0.375	9.5	9-8210	140	60	45	1.14	0.25	6.4	selec		90	245	0.50	0.25	6.4
0.500	12.7	9-8210	143	60	30	0.76	0.25	6.4			90	245	0.80	0.25	6.4
0.625	15.9	9-8210	145	60	20	0.51	0.25	6.4			90	245	Ro	lling Pierc	e
0.750	19.1	9-8210	145	60	18	0.46	0.25	6.4			90	245	Ro	lling Pierc	e
1.000	25.4	9-8210		NR, ı	manual cı	utting only	1				90	245	Ro	lling Pierc	e
1.250	31.8	9-8210		NR, ı	manual cı	utting only	1				90	245		NR	



NOTE!

* If the proper torch and lead length are selected using the 'gas pressure selector' knob and the central region (green) on the pressure dial is selected, the pressure is optimized for the selected cutting amperage.

Refer to Section 4 of the Operating Manual, "Set Operating Pressure".

** Total flow rate includes plasma and secondary gas flow.

4T.09 Recommended Cutting Speeds With Shielded Tip

	Cu	tMaster@	60i Wi	th Shielded	l Tip					Type N	laterial: N	Vild Ste	el		
		Туре	Plasma	Gas: Air					Type S	econda	ry Gas: \$	Single G	as Torch	1	
Thick	ness	Tip	Output	Amperage		d (Per ute)	Stand	doff		na Gas sure*	Flow (S	SCFH)	Pierce	Pierce Height	
Inches	mm	(Cat. No.)	Volts (VDC)	(Amps)	Inches	Meters	Inches	mm	psi	bar	Plasma	Total**	Delay (Sec)	Inches	mm
0.036	0.9	9-8208	114	40	170	4.32	 				55	170	0.00	0.2	5.1
0.06	1.5	9-8208	120	40	90	2.29	0.19	4.8	⊣		55	170	0.10	0.2	5.1
0.075	1.9	9-8208	121	40	80	2.03	0.19	4.8		ntral	55	170	0.30	0.2	5.1
0.135	3.4	9-8208	122	40	75	1.91	0.19	4.8	ı .	on on	55	170	0.40	0.2	5.1
0.188	4.8	9-8208	123	40	30	0.76	0.19	4.8		essure This is	55	170	0.60	0.2	5.1
0.25	6.4	9-8208	125	40	25	0.64	0.19	4.8		nated	55	170	1.00	0.2	5.1
0.375	9.5	9-8208	138	40	11	0.28	0.19	4.8	"	when	55	170	NR	NR	NR
0.500	12.7	9-8208	142	40	7	0.18	0.19	4.8] sele	cted.	55	170	NR	NR	NR
0.625	15.9	9-8208	152	40	3	0.08	0.19	4.8			55	170	NR	NR	NR

	Cu	tMaster@	60i Wi	th Shielded	l Tip				Тур	oe Mat	erial: Sta	inless S	teel		
		Туре	Plasma	Gas: Air					Type Se	conda	ry Gas: S	Single G	as Torch	1	
Thick	ness	Tip	Output	Amperage		d (Per lute)	Stan	doff	Plasma Press		Flow (SCFH)	Pierce	Pierce Height	
Inches	mm	(Cat. No.)	Volts (VDC)	(Amps)	Inches	Meters	Inches	mm	psi	bar	Plasma	Total**	Delay (Sec)	Inches	mm
0.036	0.9	9-8208	109	40	180	4.57	0.125				55	170	0.00	0.2	5.1
0.05	1.3	9-8208	105	40	165	4.19	0.125	3.2	Set to		55	170	0.00	0.2	5.1
0.06	1.5	9-8208	115	40	120	3.05	0.125	3.2	cen regio		55	170	0.10	0.2	5.1
0.078	2.0	9-8208	120	40	65	1.65	0.187	4.8	the pre		55	170	0.30	0.2	5.1
0.135	3.4	9-8208	125	40	25	0.64	0.187	4.8	dial. T		55	170	0.40	0.2	5.1
0.188	4.8	9-8208	132	40	20	0.51	0.187	4.8	illumir green		55	170	0.60	0.2	5.1
0.25	6.4	9-8208	130	40	15	0.38	0.187	4.8	selec		55	170	1.00	0.2	5.1
0.375	9.5	9-8208	130	40	10	0.25	0.187	4.8			55	170	NR	NR	NR

	C	utMaster	® 60i Wi	th Shielded	Tip					Type I	Material:	Aluminu	m		
		Туре	Plasma	Gas: Air					Type S	Second	ary Gas:	Single G	as Torch	1	
Thickr	ness	Tip	Output	Amperage		d (Per lute)	Stand	loff		na Gas sure*	Flow (SCFH)	Pierce	Pierce Height	
Inches	mm	(Cat. No.)	Volts (VDC)	(Amps)	Inches	Meters	Inches	mm	psi	bar	Plasma	Total**	Delay (Sec)	Inches	mm
0.032	0.8	9-8208	116	40	220	5.59	aantral			55	170	0.00	0.2	5.1	
0.051	1.3	9-8208	116	40	210	5.33	0.187	4.8		ntral	55	170	0.00	0.2	5.1
0.064	1.6	9-8208	118	40	180	4.57	0.187	4.8		on on essure	55	170	0.10	0.2	5.1
0.079	2.0	9-8208	116	40	150	3.81	0.19	4.8		This is	55	170	0.30	0.2	5.1
0.125	3.2	9-8208	130	40	75	1.91	0.19	4.8		inated	55	170	0.40	0.2	5.1
0.188	4.8	9-8208	132	40	60	1.52	0.187	4.8		when cted.	55	170	0.60	0.2	5.1
0.250	6.4	9-8208	134	40	28	0.71	0.187	4.8			55	170	1.00	0.2	5.1
0.375	9.5	9-8208	143	40	11	0.28	0.187	4.8			55	170	NR	NR	NR

	Cu	tMaster®	60i Wi	th Shielded	l Tip				1	Гуре М	laterial: I	Mild Ste	el		
		Type	Plasma	Gas: Air				1	Type Se	conda	ry Gas: 3	Single G	as Torc	h	
Thick	ness	Tip	Output	Amperage		d (Per ute)	Stand	doff	Plasm Press		Flow (SCFH)	Pierce	Pierce Height	
Inches	mm	(Cat. No.)	Volts (VDC)	(Amps)	Inches	Meters	Inches	mm	psi	bar	Plasma	Total**	Delay (Sec)	Inches	mm
0.060	1.5	9-8210	124	60	250	6.35	0.19	4.8	-		90	245	0.00	0.2	5.1
0.075	1.9	9-8210	126	60	237	6.02	0.19	4.8			90	245	0.10	0.2	5.1
0.120	3.0	9-8210	126	60	230	5.84	0.19	4.8	Set to	n the	90	245	0.10	0.2	5.1
0.135	3.4	9-8210	128	60	142	3.61	0.19	4.8	cen		90	245	0.10	0.2	5.1
0.188	4.8	9-8210	128	60	125	3.18	0.19	4.8	regio		90	245	0.20	0.2	5.1
0.250	6.4	9-8210	123	60	80	2.03	0.19	4.8	the pre dial. T		90	245	0.30	0.2	5.1
0.375	9.5	9-8210	132	60	34	0.86	0.19	4.8	illumii		90	245	0.50	0.2	5.1
0.500	12.7	9-8210	137	60	23	0.58	0.19	4.8	green		90	245	0.75	0.2	5.1
0.625	15.9	9-8210	139	60	14	0.36	0.19	4.8	seled	cted.	90	245	NR	NR	NR
0.750	19.1	9-8210	145	60	14	0.36	0.19	4.8			90	245	NR	NR	NR
1.000	25.4	9-8210	156	60	4	0.10	0.19	4.8			90	245	NR	NR	NR

	Cu	tMaster@	9 60i Wi	th Shielded	Tip				Тур	e Mate	erial: Stai	inless S	teel		
		Туре	Plasma	Gas: Air				T	ype Se	conda	ry Gas: S	ingle G	as Torcl	1	
Thick	ness	Tip	Output	Amperage		d (Per iute)	Stan	doff	Plasm Press		Flow (S	SCFH)	Pierce	Pierce Height	
Inches	mm	(Cat. No.)	Volts (VDC)	(Amps)	Inches	Meters	Inches	mm	psi	bar	Plasma	Total**	Delay (Sec)	Inches	mm
0.06	1.5	9-8210	110	60	165	4.19	0.13 3.2				90	245	0.00	0.20	5.1
0.075	1.9	9-8210	116	60	155	3.94	0.13 3.2				90	245	0.10	0.20	5.1
0.120	3.0	9-8210	115	60	125	3.18	0.13	3.2	Set to		90	245	0.10	0.20	5.1
0.135	3.4	9-8210	118	60	80	2.03	0.13	3.2	cen regio		90	245	0.10	0.20	5.1
0.188	4.8	9-8210	120	60	75	1.91	0.13	3.2	the pre		90	245	0.20	0.20	5.1
0.250	6.4	9-8210	121	60	60	1.52	0.13	3.2	dial. T		90	245	0.30	0.20	5.1
0.375	9.5	9-8210	129	60	28	0.71	0.13	3.2	illumii green		90	245	0.50	0.20	5.1
0.500	12.7	9-8210	135	60	17	0.43	0.19	4.8	seled		90	245	0.75	0.20	5.1
0.625	15.9	9-8210	135	60	14	0.36	0.19	4.8			90	245	NR	NR	NR
0.750	19.1	9-8210	142	60	10	0.25	0.19	4.8			90	245	NR	NR	NR

CUTMASTER 60i

	Cu	tMaster®	60i Wit	h Shielded	Tip	•			1	уре М	aterial: A	luminun	n		
		Type F	Plasma (as: Air				1	Type Se	conda	ry Gas: S	ingle Ga	as Torch		
Thick	Thickness Tip Output Amperage Speed (Per Minute) Inches mm (Cat. Volts (Amps) Inches Met						Stan	doff	Plasm Press		Flow (S	SCFH)	Pierce	Pierce Height	
Inches	mm	(Cat. No.)	Volts (VDC)	(Amps)	Inches	Meters	Inches	mm	psi	bar	Plasma	Total**	Delay (Sec)	Inches	mm
0.060	1.5	9-8210	105	60	350	8.89	0.13	3.2			90	245	0.00	0.20	5.1
0.075	1.9	9-8210	110	60	350	8.89	0.13	3.2	Set to	n the	90	245	0.10	0.20	5.1
0.120	3.0	9-8210	110	60	275	6.99	0.13	3.2	cen		90	245	0.10	0.20	5.1
0.188	3.4	9-8210	122	60	140	3.56	0.13	3.2	regio		90	245	0.20	0.20	5.1
0.250	6.4	9-8210	134	60	80	2.03	0.19	4.8	the pre dial. T		90	245	0.30	0.20	5.1
0.375	9.5	9-8210	140	60	45	1.14	0.19	4.8	illumii		90	245	0.50	0.20	5.1
0.500	12.7	9-8210	144	60	26	0.66	0.19	4.8	green		90	245	0.80	0.20	5.1
0.625	15.9	9-8210	145	60	19	0.48	0.19	4.8	seled	cted.	90	245	NR	NR	NR
0.750	19.1	9-8210	150	60	15	0.38	0.19	4.8]		90	245	NR	NR	NR



NOTE!

- * Gas pressure shown is for torches with leads up to 25' / 7.6 m long. For 50' / 15.2 m leads, refer to Section "Set Operating Pressure" on page <?>.
- ** Total flow rate includes plasma and secondary gas flow.

PATENT INFORMATION

Plasma Cutting Torch Patents

The following parts are covered under U.S. and Foreign Patents as follows:

Catalog #	Description	Patent(s)
9-8215	Electrode	US Pat No(s) 6163008; 6987238
		Other Pat(s) Pending
9-8213	Cartridge	US Pat No(s) 6903301; 6717096; 6936786;
		6703581; D496842; D511280; D492709; D499620;
0.9205	Т:	D504142 Other Pat(s) Pending
9-8205	Tip	US Pat No(s) 6774336; 7145099; 6933461 Other Pat(s) Pending
9-8206	Tip	US Pat No(s) 6774336; 7145099; 6933461
) 0 2 00	117	Other Pat(s) Pending
9-8207	Tip	US Pat No(s) 6774336; 7145099; 6933461
	-	Other Pat(s) Pending
9-8252	Tip	US Pat No(s) 6774336; 7145099; 6933461
0.0200	TT:	Other Pat(s) Pending
9-8208	Tip	US Pat No(s) 6774336; 7145099; 6933461
9-8209	Tip	Other Pat(s) Pending US Pat No(s) 6774336; 7145099; 6933461
7-0207	пр	Other Pat(s) Pending
9-8210	Tip	US Pat No(s) 6774336; 7145099; 6933461
	1	Other Pat(s) Pending
9-8231	Tip	US Pat No(s) 6774336; 7145099; 6933461
	_	Other Pat(s) Pending
9-8211	Tip	US Pat No(s) 6774336; 7145099; 6933461
9-8212	Tin	Other Pat(s) Pending US Pat No(s) 6774336; 7145099; 6933461
9-0212	Tip	Other Pat(s) Pending
9-8253	Tip	US Pat No(s) 6774336; 7145099; 6933461
	1	Other Pat(s) Pending
9-8225	Tip	US Pat No(s) 6774336; 7145099; 6933461
0.000	TT:	Other Pat(s) Pending
9-8226	Tip	US Pat No(s) 6774336; 7145099; 6933461
9-8227	Tip	Other Pat(s) Pending US Pat No(s) 6774336; 7145099; 6933461
)-0221	11p	Other Pat(s) Pending
9-8228	Tip	US Pat No(s) 6774336; 7145099; 6933461
	1	Other Pat(s) Pending
9-8241	Shield Cap	US Pat No(s) 6914211; D505309
0.0242	CI: 11 C	Other Pat(s) Pending
9-8243	Shield Cap	US Pat No(s) 6914211; D493183 Other Pat(s) Pending
9-8235	Shield Cap	US Pat No(s) 6914211; D505309
7 0233	Silicia Cap	Other Pat(s) Pending
9-8236	Shield Cap	US Pat No(s) 6914211; D505309
	•	Other Pat(s) Pending
9-8237	Shield Cup	US Pat No(s) 6914211; D501632; D511633
0.0000	01 : 11 6	Other Pat(s) Pending
9-8238	Shield Cap	US Pat No(s) 6914211; D496951
9-8239	Shield Cap	Other Pat(s) Pending US Pat No(s) 6914211; D496951
7-0239	ornera Cap	Other Pat(s) Pending
9-8244	Shield Cap	US Pat No(s) 6914211; D505309
	1	Other Pat(s) Pending
9-8245	Shield Cap	US Pat No(s) 6914211; D496951
		Other Pat(s) Pending

CUTMASTER 60i

The following parts are also licensed under U.S. Patent No. 5,120,930 and 5,132,512:

Catalog #	Description
9-8235	Shield Cap
9-8236	Shield Cap
9-8237	Shield Cup
9-8238	Shield Cap
9-8239	Shield Cap
9-8244	Shield Cap
9-8245	Shield Cap

Patents Pending for the following:

Quick Disconnect Torch and Quick Disconnect Torch Leads

SECTION 5 SYSTEM: SERVICE

5.01 General Maintenance



Warning! Disconnect input power before maintaining.

Maintain more often if used under severe conditions

Each Use


Visual check of torch tip and electrode




Weekly



Visually inspect the cables and leads. Replace as needed



3 Months





Art# A-13267

5.02 Maintenance Schedule



NOTE!

The actual frequency of maintenance may need to be adjusted according to the operating environment.

Daily Operational Checks or Every Six Cutting Hours:

- 1. Check torch consumable parts, replace if damaged or worn.
- 2. Check plasma and secondary supply and pressure/flow.
- 3. Purge plasma gas line to remove any moisture build-up.

Weekly or Every 30 Cutting Hours:

- 1. Check fan for proper operation and adequate air flow.
- 2. Inspect torch for any cracks or exposed wires, replace if necessary.
- 3. Inspect input power cable for damage or exposed wires, replace if necessary.

Six Months or Every 720 Cutting Hours:

- 1. Check the in-line air filter(s), clean or replace as required.
- 2. Check cables and hoses for leaks or cracks, replace if necessary.



CAUTION

Do not blow air <u>into</u> the power supply during cleaning. Blowing air into the unit can cause metal particles to interfere with sensitive electrical components and cause damage to the unit.

5.03 Common Faults

Problem - Symptom	Common Cause
Insufficient Penetration	Cutting speed too fast. Torch tilted too much. Metal too thick. Worn torch parts Cutting current too low. Non - Genuine Thermal Dynamics parts used Incorrect gas pressure
Main Arc Extinguishes	1. Cutting speed too slow. 2. Torch standoff too high from workpiece. 3. Cutting current too high. 4. Work cable disconnected. 5. Worn torch parts. 6. Non - Genuine Thermal Dynamics parts used
Excessive Dross Formation	Cutting speed too slow. Torch standoff too high from workpiece. Worn torch parts. Improper cutting current. Non - Genuine Thermal Dynamics parts used Incorrect gas pressure
Short Torch Parts Life	1. Oil or moisture in air source. 2. Exceeding system capability (material too thick). 3. Excessive pilot arc time 4. Gas pressure too low. 5. Improperly assembled torch. 6. Non - Genuine Thermal Dynamics parts used
Difficult Starting	Worn torch parts. Non - Genuine Thermal Dynamics parts used. Incorrect gas pressure.

5.04 Fault Indicator

At initial power up, the system goes through a series of self checks before it is ready for use. If during those checks it detects something is not within proper operating parameters, a fault will occur. If that happens the Fault indicator

will light followed by the Error Code ., and number in the digital display.

Error Code Indicator

Indicates when there is something that needs to be adjusted or repaired.

E001, E002, etc. Light up fault indicator also.

Error Code Description				
E001 fault.	Over Temp	Ambient temperature too high, duty cycle exceeded, fan failure or other internal		
E002	Input Fault	Input voltage outside the range of the unit or internal fault resulting in low bus voltage.		
		1phase / 3phase jumpers J300 on Bias PCB set wrong.		
E004	PIP Fault	Parts in Place fault. Shield cup not in place or tight.		
E005	PIC Fault	Parts in Contact fault. Missing or worn tip/start cartridge or electrode.		
		Inlet pressure exceeds rating causing continuous gas flow.		
E009	Fan Fault	Fan failed or disconnected.		
E010	Low Output Current			
		Work Lead current less than output current setting. Shorted pilot switch or defective current sensor possible.		
E012	Output Fault	Tip to electrode voltage too low. Consumables fail to separate when gas flows, start cartridge stuck, failed power supply, no output or shorted torch body.		
E014	Trigger Fault	Torch trigger (start signal) active at start up.		
E016	Pressure Fault	Low Air/Gas pressure. Output pressure too low for selected parameters.		

5.05 Basic Troubleshooting Guide



WARNING


There are extremely dangerous voltage and power levels present inside this unit. Do not attempt to diagnose or repair unless you have had training in power electronics measurement and troubleshooting techniques.

Problem - Symptom	Possible Cause	Recommended Action
ON / OFF Switch		Turn primary power disconnect switch to ON position.
is ON but the A/C	Primary power disconnect is in OFF position. Primary fuses / breakers are blown or tripped. Faulty components in unit.	a) Have qualified person check primary fuses / breakers. b) Connect unit to known good primary power receptacle Return to authorized service center for repair or replacement.
Fault indicator flashing, Error Code E002	Primary input voltage problem. Eaulty components in unit.	Have qualified person check primary voltage to insure it meets unit requirements see Section "2.05 Input Wiring Specifications" on page . Return to authorized service center for repair or replacement.
TEMPERATURE indicator ON . FAULT indicator flashing. Error Code E001	Air flow through or around the unit is obstructed. Duty cycle of the unit has been exceeded. Failed components in unit.	Refer to clearance information — see Section "2.04 Power Supply Specifications" on page Allow unit to cool. Return to authorized service center for repair or replacement.
GAS LED 0FF ,	Gas supply not connected to	Connect gas supply to unit.
FAULT and MIN pressure indicators	unit. 2. Gas supply not turned ON . 3. Gas supply pressure too low. 4. Failed components in unit.	2. Turn gas supply ON . 3. Set air supply inlet pressure to unit to 120 psi. Set leads length to match the actual length being used. 4. Return to authorized service center for repair or replacement.
FAULT and indicators flashing. Error Code E004	1	 Hand tighten the shield cup until it is snug. Insure torch ATC is securely fastened to unit. Replace torch and leads or return to authorized service center for repair or replacement. Return to authorized service center for repair or replacement.
flashing. Error Code E014	1. Start signal is active when ON/OFF SWITCH is turned to ON position. 2. Problem in the torch and leads switch circuit. 3. Failed components in unit.	1. Start can be active for one of the following: • Hand torch switch held closed • Hand pendant switch held closed • CNC START signal is active low Release the START signal source 2. Replace torch and leads or return to authorized service center for repair or replacement. 3. Return to authorized service center for repair or replacement.
FAULT indicators flashing. Error code E005	1. Torch shield cup is loose. 2. Torch tip, electrode or starter cartridge missing. 3. Torch start cartridge is stuck. 4. Unit inlet gas pressure is too high causing continuous gas flow. 5. Open conductor in torch leads.	1. Tighten shield cup by hand. Do not overtighten. 2. Turn OFF power supply. Remove shield cup. Install missing parts. 3. Turn OFF power supply. Bleed down system pressure. Remove shield cup, tip and start cartridge. Check start cartridge lower end fitting for free movement. Replace if fitting does not move freely. 4. Decrease gas supply pressure to 125 PSI or less. 5. Replace torch and leads or return to authorized service center for repair or replacement.
	Problem in the torch and leads switch circuit. Failed components in unit.	6. Replace torch and leads or return to authorized service center for repair or replacement. 7. Return to authorized service center for repair or replacement

Problem - Symptom	Possible Cause	Recommended Action
Nothing happens when torch switch or remote switch	Problem in the torch and leads switch circuit (Remote pendant switch circuit).	Take Torch and Leads (Remote Pendant) to Authorized Repair Facility.
is closed (Or CNC START signal is	2. CNC Controller device not providing Start signal.	2. Contact Controller manufacturer.
active) No gas flow, DC LED OFF.	3. Failed components in unit.	3. Return to authorized service center for repair or replacement.
	wrong position. 2. Torch starter cartridge is stuck.	Remove shield cup from torch; check upper O-ring position; correct if necessary. Turn OFF power supply. Bleed down system pressure. Remove shield cup, tip and starter cartridge. Check starter cartridge lower end fitting for free movement. Replace if fitting does not move freely.
	3. Worn or faulty torch parts. 4. Shorted Torch.	3. Inspect torch consumable parts. Replace if necessary. 4. Replace torch and leads or return to an authorized service center for repair.
No Fault lights ON, no arc in torch.	1. Failed components in unit.	Return to an authorized service center for repair.
FAULT indicators flashing Error code E024 or E031	1. Internal Error	1. Turn the ON / OFF switch OFF then back ON again. If that does not clear the fault, return to an authorized service center for repair.
Pilot arc is ON but cutting arc will not	Work cable not connected to work piece.	1. Connect work cable.
establish		Replace work cable. Return to an authorized service center for repair.
	shorted 2. HCT1 Current Sensor or harness	1. Perform the resistance tests at #7 in section "Power Off Tests". 2. With the ouput current set at 60A, test the voltage at J601-3 (J601-4 common). It should be 2.4V. If it is, then the sensor is bad. If it is higher than 2.4V then check the harness for continuity.
Torch cutting is diminished	1	Check and adjust to proper setting. Check torch consumables and replace as needed. Check the connection of the Work Lead to the work piece.
	1 .	4. Reduce cutting speed.5. Refer to "Check air quality" in Section 3 Torch.6. Return to an authorized service center for repair.

Art #A-13266

Sequence of Operation (Block Diagram)



5.06 Power Supply Basic Parts Replacement




WARNING

Disconnect primary power to the system before disassembling the torch, leads, or power supply.

This section describes procedures for basic parts replacement. For more detailed parts replacement procedures, refer to the Power Supply Service Manual.

A. Filter Element Assembly Replacement

The Filter Element Assembly (9-0116) is in the rear panel. For better system performance, the filter element should be checked per the Maintenance Schedule (Section 5.02), and either cleaned or replaced.



1. Remove power from the power supply; turn OFF the gas supply and bleed down the system.



2. Remove the clear filter bowl with wrench

provided with the system 9-9675.



NOTE!


Filter replacement part numbers can be found in Section 6 of this manual

3. Remove the filter element and clean or replace..



NOTE!

If replacing or cleaning just the filter element refer to the following illustration for disassembly.




- 4. Install the new or cleaned assembly by reversing these procedures.
- 5. Turn ON the air supply and check for leaks before reinstalling the cover.

Optional Single-Stage Filter Element Replacement

These instructions apply to power supplies where the optional Single-Stage Filter has been installed.

The Power Supply shuts down automatically when the Filter Element becomes completely saturated. The Filter Element can be removed from its housing, dried, and reused. Allow 24 hours for Element to dry. Refer to Section 6, Parts List, for replacement filter element catalog number.

- 1. Remove power from power supply.
- 2. Shut OFF air supply and bleed down system before disassembling Filter to change Filter Element.
- 3. Disconnect gas supply hose.
- 4. Turn the Filter Housing Cover counter-clockwise and remove it. The Filter Element is located inside the Housing.



Optional Single-Stage Filter Element Replacement

- 5. Remove the Filter Element from the Housing and set Element aside to dry.
- 6. Wipe inside of housing clean, then insert the replacement Filter Element open side first.
- 7. Replace Housing on Cover.
- 8. Reattach gas supply.



NOTE!

If unit leaks between housing and cover, inspect the O-ring for cuts or other damage.

Optional Two-Stage Filter Element Replacement

The Two-Stage Air Filter has two Filter Elements. When the Filter Elements become dirty the Power Supply will continue to operate but cut quality may become unacceptable. Refer to Section 6, Parts List, for replacement filter element catalog number.


- 1. Shut OFF primary input power.
- 2. Shut OFF air supply and bleed down system.



WARNING

Always turn OFF the air supply and bleed the system before disassembling the Filter Assembly as injury could result.

- 3. Loosen the two bolts on the top of the Filter Assembly enough to allow the Filter Elements to move freely.
- 4. Note the location and orientation of the old Filter Elements.
- 5. Slide out the old Filter Elements.



Optional Two-Stage Filter Replacement

- 6. Slide the replacement Filter Elements into the Filter Assembly, with the same orientation as noted in Step 4 above.
- 7. Hand tighten the two bolts evenly, then torque each bolt to 20 30 in-lbs (2.3 3.4 Nm). Improper torque may damage the gasket.
- 8. Slowly apply air pressure to the assembly, checking for leaks.



NOTE!

A small amount of air leakage from the bottom fitting is normal.



NOTE!

Filter replacement part numbers can be found in Section 6 of this manual

This completes the parts replacement procedures.



This Page Intentionally Blank

SECTION 5 TORCH: SERVICE

5T.01 General Maintenance



NOTE!

Refer to Previous "Section 5: System" for common and fault indicator descriptions.

Cleaning Torch

Even if precautions are taken to use only clean air with a torch, eventually the inside of the torch becomes coated with residue. This buildup can affect the pilot arc initiation and the overall cut quality of the torch.



WARNING

Disconnect primary power to the system before disassembling the torch or torch leads.

DO NOT touch any internal torch parts while the AC indicator light of the Power Supply is ON.

The inside of the torch should be cleaned with electrical contact cleaner using a cotton swab or soft wet rag. In severe cases, the torch can be removed from the leads and cleaned more thoroughly by pouring electrical contact cleaner into the torch and blowing it through with compressed air.




CAUTION

Dry the torch thoroughly before reinstalling.


O-Ring Lubrication

An O-Ring on the Torch Head and ATC Male Connector requires lubrication on a scheduled basis. This will allow the O-Rings to remain pliable and provide a proper seal. The O-Rings will dry out, becoming hard and cracked if the lubricant is not used on a regular basis. This can lead to potential performance problems.

It is recommended to apply a very light film of O-Ring lubricant (Catalog #8-4025) to the O-Rings on a weekly basis.



Torch Head O-Ring





NOTE!

DO NOT use other lubricants or grease, they may not be designed to operate within high temperatures or may contain "unknown elements" that may react with the atmosphere. This reaction can leave contaminants inside the torch. Either of these conditions can lead to inconsistent performance or poor parts life.

5T.02 Inspection and Replacement of Consumable Torch Parts



WARNING

Disconnect primary power to the system before disassembling the torch or torch leads.

DO NOT touch any internal torch parts while the AC indicator light of the Power Supply is ON.

Remove the consumable torch parts as follows:



NOTE!

The shield cup holds the tip and starter cartridge in place. Position the torch with the shield cup facing upward to prevent these parts from falling out when the cup is removed.


 Unscrew and remove the shield cup from the torch.



NOTE!


Slag built up on the shield cup that cannot be removed may effect the performance of the system.

2. Inspect the cup for damage. Wipe it clean or replace if damaged.




Shield Cups

3. On torches with a shield cup body and a shield cap or deflector, ensure that the cap or deflector is threaded snugly against the shield cup body. In shielded drag cutting operations (only), there may be an O-Ring between the shield cup body and drag shield cap. Do not lubricate the O-Ring.




4. Remove the tip. Check for excessive wear (indicated by an elongated or oversized orifice). Clean or replace the tip if necessary.




Example of Tip Wear

 Remove the starter cartridge. Check for excessive wear, plugged gas holes, or discoloration. Check the lower end fitting for free motion. Replace if necessary.



Art # A-08064 AC

6. Pull the Electrode straight out of the Torch Head. Check the face of the electrode for excessive wear. Refer to the following figure.



- 7. Reinstall the Electrode by pushing it straight into the torch head until it clicks.
- 8. Reinstall the desired starter cartridge and tip into the torch head.
- 9. Hand tighten the shield cup until it is seated on the torch head. If resistance is felt when installing the cup, check the threads before proceeding.

This completes the parts replacement procedures.

SECTION 6: PARTS LISTS

6.01 Introduction

A. Parts List Breakdown

The parts list provide a breakdown of all replaceable components. The parts lists are arranged as follows:

6.03	Power Supply Replacement
6.04	Replacement Power Supply Parts
6.05	Options and Accessories
6.06	External Replacement Parts (Plastic)
6.07	Replacement Parts for SL60QD™ Hand Torch
6.08	Torch Consumable Parts (SL60 / SL60QD TM)
6.09	Torch Consumable Parts SL100



NOTE!

Parts listed without item numbers are not shown, but may be ordered by the catalog number shown.

B. Returns

If a product must be returned for service, contact your distributor. Materials returned without proper authorization will not be accepted.

6.02 Ordering Information

Order replacement parts by catalog number and complete description of the part or assembly, as listed in the parts list for each type item. Also include the model and serial number of the power supply. Address all inquiries to your authorized distributor.

6.03 Power Supply Replacement

The following items are included with the replacement power supply: work cable & clamp, input power cable, gas pressure regulator / filter, and operating manual.


Qty	Description	Catalog #
1	CutMaster 60i Power Supply 208/230 - 480VAC, SINGLE Phase , 60Hz,	-
	with input power cable and plug	3-5630-1
	208/230 - 480VAC, THREE Phase, 60Hz,	
	with input power cable and plug	3-5630-2


6.04 Replacement Power Supply Parts


Qtv	Description	Catalog #
1	Filter Assembly Replacement Element (Factory filter)	9-0116
1	SINGLE phase Input Power Cord for 208/480 V Power Supply	9-9701
1	THREE phase Input Power Cord for 208/480 V Power Supply	9-9706

6.05 Options and Accessories

Oty	Description	Catalog #
1	Single - Stage Filter Kit (includes Filter & Hose)	7-7507
1	Replacement Filter Body	9-7740
1	Replacement Filter Hose (not shown)	9-7742
2	Replacement Filter Element	9-7741
1	Two - Stage Filter Kit (includes Hose & Mounting Screws)	9-9387
1	Two - Stage Air Filter Assembly	9-7527
1	First Stage Cartridge	9-1021
1	Second Stage Cartridge	9-1022
1	Work Cable #8 with 50mm Dinse plug	9-9692
1	Multi - Purpose Cart	7-8888
1	Filter Wrench (Factory Filter)	9-9675








Optional Two - Stage Filter Kit


6.06 External Replacement Parts (Plastic)


<u>Item #</u>	Qty	Description	Catalog #
1	1	Handle, Case Top	9-9702
2	1	Bezel, Side Frame RH	9-9703
3	1	Handle, CM60i (3 total)	9-9665
4	1	Foot, Case Front	9-9694
5	1	Bezel, Side Frame LH	9-9704
6	1	Foot, Case Rear	9-9693
Screws and r	nuts can	be obtained at a local hardware store.	
a		M5x0.8x12mm screw	
b		M5x0.8x16mm screw	
С		M5x0.8 nut	




6.07 Replacement Parts for Hand Torch

 tem #	Qty	Description	Catalog #
1	1	Torch Handle Assembly Replacement	7-5680
2		Leads Assemblies with ATC connector and Quick Connectors	
	1	SL60QD TM , 20 - foot Leads Assembly with ATC and QD connectors	4-5604
	1	SL60QD™, 50 - foot Leads Assembly with ATC and QD connectors	4-5605
1&2	1	Torch and Leads Assembly, 20 - foot	7-5604
1&2	1	Torch and Leads Assembly, 50 - foot	7-5605






6.08 Torch Consumable Parts (SL60)




Δrt # Δ-13147 ΔC

6.09 Torch Consumable Parts (SL100)



APPENDIX 1: DATA TAG INFORMATION



NOTES:

- Symbol shown indicates single- or three-phase AC input, static frequency converter-transformer-rectifier, DC output.
- 2. Indicates input voltages for this power supply. Most power supplies carry a label on the bottom of the unit showing input voltage requirements for the power supply as built.
- 3. Top row: Duty cycle values.

Duty cycle values meet or exceed the IEC specified rating.

Second row: Rated cutting current values. Third row: Conventional load voltage values.

4. Sections of the Data Tag may be applied to separate areas of the power supply.

Standard Symbols


AC DC Ø Phase


Art # A-13265 AB

Manual 0-5436 APPENDIX A-1

APPENDIX 2: TORCH PIN - OUT DIAGRAMS

Hand Torch Pin - Out Diagram





Front View

Pilot

Negative / Plasma


4 - Switch

3 - Switch

2 - PIP


1 - PIP


Mechanized (Machine) Torch Pin - Out Diagram



Art # A-03799


Automation SL100SV Torch Pin - out Diagram






APPENDIX 3: TORCH CONNECTION DIAGRAMS

A. Hand Torch Connection Diagram




Art # A-13334


B. Mechanized Torch Connection Diagram




Art # A-13335


APPENDIX 4: SYSTEM SCHEMATIC. 1PHASE 208/460V UNITS






APPENDIX 5: SYSTEM SCHEMATIC. 3PHASE 208/460V UNITS





APPENDIX 6: Publication History

Cover Date	Rev.	Change(s)
Dec. 12, 2016	AA	Manual released.
Apr. 3, 2017	AB	Updated Manual to include 3phase systems. VCR-02204



THE AMERICAS

Denton, TX USA
U.S. Customer Care
Ph 1-800-426-1888 (tollfree)
Fax: 1-800-535-0557 (tollfree)

International Customer Care
Ph 1-940-381-1212

Ph 1-940-381-1212 Fax: 1-940-483-8178

Miami, FL USA Sales Office, Latin America Ph 1-954-727-8371 Fax: 1-954-727-8376

Oakville, Ontario, Canada Canada Customer Care Ph 1-905-827-4515 Fax: 1-800-588-1714 (tollfree)



U.S. Customer Care: 800-426-1888 / FAX 800-535-0557 Canada Customer Care: 905-827-4515 / FAX 800-588-1714 International Customer Care: 940-381-1212 / FAX 940-483-8178